


Model: YY2985



Headset / Casque d'écoute: YY2985
FCC ID: AK8YY2985
IC: 409B-YY2985

FOR CUSTOMERS IN CANADA (INCLUDING IN THE PROVINCE OF QUEBEC)
ALL INSTRUCTIONS AND STATEMENTS WHICH ARE NECESSARY FOR
CANADIAN CUSTOMERS ARE PROVIDED IN ENGLISH AND FRENCH.
OTHER INSTRUCTIONS AND STATEMENTS NOT PROVIDED IN ENGLISH
AND FRENCH ARE NOT FOR CANADIAN CUSTOMERS (INCLUDING IN THE
PROVINCE OF QUEBEC).

POUR LES CLIENTS AU CANADA (Y COMPRIS DANS LA PROVINCE DE
QUÉBEC)
TOUTES LES INSTRUCTIONS ET DÉCLARATIONS NÉCESSAIRES POUR LES
CLIENTS CANADIENS SONT FOURNIES EN ANGLAIS ET EN FRANÇAIS. LES
AUTRES INSTRUCTIONS ET ÉNONCÉS NON FOURNIS EN ANGLAIS ET EN
FRANÇAIS NE SONT PAS DESTINÉS AUX CLIENTS CANADIENS (Y COMPRIS
AU QUÉBEC).

English

Wireless Noise Canceling Stereo Headset

Model: YY2985

The term "product" in this document refers to the unit or its accessories.

FOR UNITED STATES CUSTOMERS. NOT APPLICABLE IN CANADA,
INCLUDING IN THE PROVINCE OF QUEBEC.

POUR LES CONSOMMATEURS AUX ÉTATS-UNIS. NON APPLICABLE AU
CANADA, Y COMPRIS LA PROVINCE DE QUÉBEC.

Owner's Record
Record the model and serial numbers in the spaces provided below
and store them safely.
Refer to them whenever you call your Sony dealer regarding this
product.
Model No. _____
Serial No. _____
The model and serial numbers to be recorded are located in the
following places.
• the bottom of the charging case

Do not install the product in a confined space, such as a bookcase or
built-in cabinet.

Do not expose the batteries (battery pack or batteries installed) to
excessive heat, such as sunshine, fire or the like, for a long time.
Do not subject the batteries to extreme low temperature conditions that
may result in overheating and thermal runaway.
Do not dismantle, open, or shred secondary batteries.
In the event of a secondary battery leaking, do not allow the liquid to come
in contact with the skin or eyes. If contact has been made, wash the
affected area with copious amounts of water and seek medical advice.
Secondary batteries need to be charged before use. Always refer to the
manufacturer's instructions or product manual for proper charging
instructions.
After extended periods of storage, it may be necessary to charge and
discharge the secondary batteries several times to obtain maximum
performance.
Dispose of properly.

Charging this product

Place the headset units into the charging case.
Use the supplied USB Type-C® cable and a commercially available USB AC
adaptor.
Connect the USB AC adaptor to the charging case using the USB Type-C
cable, then connect the USB AC adaptor to an AC outlet.

DISPOSAL OF RECHARGEABLE BATTERIES

You can help preserve our environment by returning your used
rechargeable batteries to the collection and recycling location nearest you.
For more information regarding recycling of rechargeable batteries, visit
www.sony.com/ecotrade
Caution: Do not handle damaged or leaking rechargeable batteries.

⚠ WARNING

- **INGESTION HAZARD:** This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as **2 hours**.
- **KEEP** new and used batteries **OUT OF REACH of CHILDREN**.
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.



- Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.
- Even used batteries may cause severe injury or death.
- Call a local poison control center for treatment information.
- Compatible Battery Type
Battery type: Z55FA
- Nominal Battery Voltage
Nominal Voltage: 3.85 V
- Non-rechargeable batteries are not to be recharged.
- Do not force discharge, recharge, disassemble, heat above 45 °C (113 °F) or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.
- This product contains non-replaceable button/coin cell batteries.

FOR UNITED STATES CUSTOMERS. NOT APPLICABLE IN CANADA,
INCLUDING IN THE PROVINCE OF QUEBEC.

POUR LES CONSOMMATEURS AUX ÉTATS-UNIS. NON APPLICABLE AU
CANADA, Y COMPRIS LA PROVINCE DE QUÉBEC.

You are cautioned that any changes or modifications not expressly
approved in this manual could void your authority to operate this unit.

If you have any questions about this product:

Visit: https://www.sony.com/electronics/support
Contact: Sony Customer Information Service Center at 1-800-222-7669
Supplier's Declaration of Conformity
Trade Name: SONY
Model: YY2985
Responsible Party: Sony Electronics Inc.
Address: 16535 Via Esprillo, San Diego, CA 92127 U.S.A.
Telephone Number: 858-942-2230

This device complies with part 15 of the FCC Rules. Operation is subject
to the following two conditions:
(1) This device may not cause harmful interference, and
(2) this device must accept any interference received, including
interference that may cause undesired operation.

NOTE:

This unit has been tested and found to comply with the limits for a
Class B digital device, pursuant to part 15 of the FCC Rules. These limits
are designed to provide reasonable protection against harmful
interference in a residential installation. This unit generates, uses, and
can radiate radio frequency energy and, if not installed and used in
accordance with the instructions, may cause harmful interference to
radio communications.

However, there is no guarantee that interference will not occur in a
particular installation. If this unit does cause harmful interference to
radio or television reception, which can be determined by turning the
unit off and on, the user is encouraged to try to correct the interference
by one or more of the following measures:
• Reorient or relocate the receiving antenna.
• Increase the separation between the unit and receiver.
• Connect the unit into an outlet on a circuit different from that to
which the receiver is connected.
• Consult the dealer or an experienced radio/TV technician for help.

This unit must not be co-located or operated in conjunction with any
other antenna or transmitter.

For customers in Canada

This unit contains licence-exempt transmitter(s)/receiver(s) that comply
with Innovation, Science and Economic Development Canada's
licence-exempt RSS(s). Operation is subject to the following two
conditions:
(1) This unit may not cause interference; and
(2) This unit must accept any interference, including interference that
may cause undesired operation of the unit.

The available scientific evidence does not show that any health problems
are associated with using low power wireless devices. There is no proof,
however, that these low power wireless devices are absolutely safe. Low
power wireless devices emit low levels of radio frequency energy (RF) in
the microwave range while being used. Whereas high levels of RF can
produce health effects (by heating tissue), exposure of low-level RF that
does not produce heating effects causes no known adverse health effects.
Many studies of low-level RF exposures have not found any biological
effects. Some studies have suggested that some biological effects might
occur, but such findings have not been confirmed by additional research.
The unit has been tested and found to comply with FCC/ISED radiation
exposure limits set forth for an uncontrolled environment and meets the
FCC radio frequency (RF) Exposure Guidelines and RSS-102 of the ISED
radio frequency (RF) Exposure rules.

High volume may adversely affect your hearing.

Do not use the unit while walking, driving, or cycling. Doing so may cause
traffic accidents.

Do not use in hazardous areas unless the surrounding sound can be heard.

If water or foreign matter enters the unit, it may result in fire or electric
shock. If water or foreign matter enters the unit, stop use immediately and
consult your nearest Sony dealer. In particular, be careful in the following
cases.

- When using the unit near a sink or liquid container
Be careful that the unit does not fall into a sink or container filled with
water.
- When using the unit in the rain or snow, or in humid locations

For details on the effects of contact with the human body from the mobile
phone or other wireless devices connected to the unit, refer to the
instruction manual of the wireless device.

If the earbud tips are not securely attached, they may fall off and remain
inside the ear during use. Make sure that the earbud tips are securely
attached before use.

Never insert the USB plug when the unit or charging cable is wet. If the
USB plug is inserted while the unit or charging cable is wet, a short circuit
may occur due to liquid (tap water, seawater, soft drink, etc.) or foreign
matter on the unit or charging cable, and cause abnormal heat generation
or malfunction.

This product has magnet(s) which may interfere with pacemakers,
programmable shunt valves for hydrocephalus treatment, or other medical
devices. Do not place this product close to persons who use such medical
devices. Consult your doctor before using this product if you use any such
medical device.

This product has magnet(s). Swallowing magnet(s) could cause serious
harm, such as choking hazard or intestinal injuries. If magnets (or a
magnet) were swallowed, consult a doctor immediately. Keep this product
away from children or other supervised individuals to prevent accidental
ingestion.

There is a danger that this unit or its small parts may be swallowed. After
use, store the unit in the charging case and store in a location out of reach
of small children.

Note about static electricity

If you use the unit when the air is dry, you may experience discomfort due
to static electricity accumulated on your body. This is not a malfunction of
the unit. You can reduce the effect by wearing clothes made of natural
materials that do not easily generate static electricity.

IMPORTANT

The factory default setting of the voice guidance for this unit is English.
The voice guidance can be heard from the unit in the following situations:
• When the remaining battery level is low and recharge is recommended:
"Low battery"
• When automatically turning off due to low battery: "Battery is empty"
• When entering pairing mode: "Pairing"

Precautions

The URL on the cover will help you access the help guide that
describes useful notes or procedures in details.

On water resistant of the unit

- The charging case is not water resistant.
- Unless the unit is used correctly, water may get into the unit and
cause fire, electrocution, or malfunctions. Note the following cautions
carefully and use the unit correctly.

To maintain water resistant performance

Carefully note the precautions below to ensure proper use of the unit.
• Do not splash water forcibly into the sound output holes.
• Do not drop the unit into water, and do not use underwater.
• Do not allow the unit to remain wet in a cold environment, as the
water may freeze. To prevent malfunction, make sure to wipe off any
water after use.
• Do not place the unit in water or use it in a humid place such as a
bathroom.
• Do not drop the unit or expose it to mechanical shock. Doing so may
deform or damage the unit, resulting in deterioration of water
resistance performance.

On BLUETOOTH® communications

• Microwaves emitting from a Bluetooth device may affect the operation of
electronic medical devices. Turn off this unit and other Bluetooth devices
in the following locations, as it may cause an accident:
– in hospitals, near priority seating in trains, locations where inflammable
gas is present, near automatic doors, or near fire alarms.

On charging the unit

- Observe the following precautions. Failure to do so may cause fire, burns,
injury, or electric shock.
– Do not attach metallic objects (such as stickers made of materials
containing metal) to the wireless charger or the unit.

- When using wireless charging, remove the cover attached to the
charging case, and do not place metallic objects (such as straps or clips
containing metal) on the wireless charger.
- If something unusual occurs during wireless charging, such as unusual
odor, unusual sound, smoke, overheating, or deformation, carefully and
safely remove the unit from the wireless charger.
- When you have medical electric devices such as pacemakers or
defibrillators implanted, consult your doctor before using the wireless
charging pad. Radio waves may affect the operations of the medical
electric devices.
- Be sure to use the supplied USB Type-C cable.

Notes on wearing the unit

- After use, remove the headphones slowly.
- Because the earbud tips achieve a tight seal in the ears, forcibly pressing
them in or quickly pulling them out can result in eardrum damage.
When wearing the earbud tips, the speaker diaphragm may produce a
click sound. This is not a malfunction.

On the earbud tips (Noise isolation earbud tips)

- Earbud tips are fitted within the ear, so there is an increased risk of
irritation of the ear canal. If you experience any discomfort, discontinue
use.
- Earbud tips are consumables and may deteriorate or break after
long-term use and storage. If the tips deteriorate or become damaged,
the audio performance such as sound quality and noise canceling will
become compromised. Replace them regularly.
- Also, if an earbud tip becomes damaged, such as cracking, peeling,
chipping, or mesh becomes torn, the earbud tip or part of it may remain
in your ear and cause injury or illness. If you see any damage, be sure to
replace the tip.
- Avoid washing with water, wet wipes, and the use of organic solvents
such as alcohol, as these can cause premature deterioration.
- If foreign objects such as earwax are attached to the mesh part of the
earbud tip, the sound may become muffled or difficult to hear.
Remove the earbud tip from the headset, apply a cotton swab lightly to
the mesh part, and rotate the cotton swab slowly to wipe off the dirt. Be
careful not to tear the mesh part.

Other notes

- If you experience discomfort while using the unit, stop using it
immediately.
- If you have any questions or problems concerning this unit that are not
covered in this manual, please consult your nearest Sony dealer.

Specifications

Headset

Power source:

DC 5 V (Using a commercially available USB AC Adaptor)
Using built-in lithium-ion batteries (Product Operation Power: DC
3.85 V)

Rated power consumption:

1.5 W (Headset), 4 W (Charging case)

Operating temperature:

0 °C to 40 °C (32 °F to 104 °F)

Included items:

Wireless Noise Canceling Stereo Headset (1)
USB Type-C® cable (USB-A to USB-C®) (1)
Noise isolation earbud tips (XS (2), S (2), M (2), L (2))
Charging case (1)
Documents (1 set)

Communication specification

Communication system:

Bluetooth

Design and specifications are subject to change without notice.

System requirements for battery charge using USB

USB AC adaptor:

A commercially available USB AC adaptor capable of supplying an output
current of 0.5 A (500 mA) or more.
• Do not use a USB adaptor that exceeds the maximum output of 13 W (5 V,
2.6 A).

Trademarks

- The Bluetooth® word mark and logos are registered trademarks owned
by Bluetooth SIG, Inc. and any use of such marks by Sony Group
Corporation and its subsidiaries is under license.
- USB Type-C® and USB-C® are registered trademarks of USB Implementers
Forum.
- LDAC and LDAC logo are trademarks of Sony Group Corporation or its
affiliates.
- All other trademarks and registered trademarks are trademarks or
registered trademarks of their respective holders. In this manual, ™ and ®
marks are not specified.

Licenses

- This product contains software that Sony uses under a licensing
agreement with the owner of its copyright. We are obligated to
announce the contents of the agreement to customers under
requirement by the owner of copyright for the software. Please access
the following URL and read the contents of the license.
- Services offered by third parties may be changed, suspended, or
terminated without prior notice. Sony does not bear any responsibility
in these sorts of situations.