


CS50 WIRELESS OFFICE HEADSET SYSTEM



QUICK START USER GUIDE

WELCOME

Thank you for selecting the CS50 Wireless Office Headset System from Plantronics. You have made the right choice for comfort and versatility.

This system allows your telephone to use a cordless Plantronics headset through an adapting base. It offers hands-free convenience and long-range workspace mobility.

With the use of an optional handset lifter, the user can remotely receive the telephone's ring alert and can answer the call by simply pushing the talk button on the headset.

This side of the guide has the Important Safety Instructions that should be read prior to set up and use of your system. The quick start part on the other side identifies the components, has five steps to get you started, and test the system.

Most telephones will work with little or no adjustments. This system is not designed to work with phones which have the dial pad built into the handset.

The Product Information Booklet in all languages is online at: <http://www.plantronics.com/documentation/>

Choose your preferred language and the Plantronics model number "CS50" to access complete user documentation including this Quick Start Guide and the Product Information Booklet which has more on the system's operation, adjustments, and troubleshooting.

IMPORTANT SAFETY INSTRUCTION



When using your telephone equipment these basic safety precautions should be followed to reduce the risk of fire, electric shock, and injury to persons.

1. Read and understand all instructions.
2. Follow all warnings and instructions marked on the product. The symbol  identifies and alerts the user to the presence of important operating, safety, and service instructions.
3. Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.
4. Do not locate this product near water, for example, near a bathtub, or sink, in a wet basement or near a swimming pool.
5. This product should never be placed near or over a radiator or heat register. It should not be placed in a built-in installation unless proper ventilation is provided.
6. Do not allow anything to rest on the power cord. Do not locate this product where persons walking on it will damage the cord.
7. Do not overload outlets and extension cords as this can result in risk of fire or electric shock.

Printed in China 63913-01 (7-03)

BATTERY PRECAUTIONS



To reduce the risk of fire or injury to persons, read and follow these instructions.

1. Use only the battery pack supplied with this product. Plantronics part number 64399-01.
2. Do not dispose of battery pack in a fire. The cells may explode. Check with local codes for possible disposal instructions.
3. Do not open or mutilate battery pack. Released electrolyte is corrosive and may cause damage to eyes or skin and may be toxic if swallowed.
4. Exercise care in handling the battery pack in order not to short the battery contacts with conducting materials such as rings, bracelets, and keys. The battery or conductor may overheat and cause burns.
5. Charge the battery pack in accordance with instructions supplied with this unit.
6. Observe proper orientation between battery pack and charger contacts.
7. Never allow children to play with the headset/adaptor—small parts may be a choking hazard.
Batteries can be swallowed by children and are dangerous if swallowed. Always store and dispose of batteries where children can't reach them.

The Plantronics Technical Assistance Center (TAC) is ready to assist you! Dial (800) 544-4660 x5538 Sunday 5P.M. through Friday, 5P.M. Pacific Time or visit the Support section of our website at www.plantronics.com. For accessibility information also call the Technical Assistance Center.

SAVE THESE INSTRUCTIONS

© 2003 Plantronics, Inc. All rights reserved. Plantronics, the logo design, or registered trademarks and the logo design combined, and IntelliStand are trademarks of Plantronics, Inc. All other trademarks are the property of the respective owners.
Patent U.S. 5,210,791 and Patents Pending

www.plantronics.com
(800) 544-4660
Santa Cruz, California 95060
345 Encinal Street

SAFETY INSTRUCTIONS CONTINUED

8. Never disassemble or push objects of any kind into the product as this may short out parts which could result in a fire or electric shock. Never spill liquid of any kind on the product.
9. Use caution when installing or modifying telephone lines.
10. This product is intended to be powered by a Listed Class 2 Direct Plug-In Power Unit rated 9VDC 800mA. Plantronics Part No. 45561-02, rated at an input voltage of 120 VAC, 60Hz and an output voltage of 9 VDC at 800mA.
11. This product requires AC power in order to operate. In order to have phone service during a power outage, have another telephone available that is powered only by the telephone line.
12. Keep all product cords and cables away from operating machinery.
13. Avoid using telephone equipment during an electrical storm.
14. Do not use this equipment to report a gas leak in the vicinity of a gas leak.

FCC REGISTRATION INFORMATION

FCC Requirements—Part 15

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception which can be determined by turning the radio or television off and on, the user is encouraged to try to correct interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on another circuit.
4. Consult the dealer or an experienced radio/TV technician for help.

FCC Requirements—Part 68

This equipment complies with Part 68 of the FCC Rules and the requirements adopted by ACTA. On the bottom of the base unit of this equipment is a label that contains, a product identifier in the format US:AAAEQ##TXXXX. If requested, this information must be provided to your telephone company.

If this equipment causes harm to the telephone network, the telephone company will notify you in advance that temporary discontinuance of service may be required. But if advance notice isn't practical, the telephone company will notify the customer as soon as possible. Also, you will be advised of your right to file a complaint with the FCC if you believe it is necessary.

The telephone company may make changes in its facilities, equipment, operations or procedures that could affect the proper functioning of your equipment. If they do, you will be notified in advance in order for you to make necessary modifications to maintain uninterrupted service.

If trouble is experienced with this unit, for repair or warranty information, please contact customer service at the address and phone listed in the Warranty section of this User's Guide.

INDUSTRY CANADA NOTICE

This telephone is hearing aid compatible.

Notice: The Industry Canada label identifies certified equipment. This certification means that the equipment meets certain telecommunications network protective, operational and safety requirements. The Department does not guarantee the equipment will operate to the users satisfaction.

Before installing this equipment, users should ensure that it is permissible to be connected to the facilities of the local telecommunications company. The equipment must also be installed using an acceptable method of connection. In some cases, the company's inside wiring associated with a single line individual service may be extended by means of a certified connector assembly (telephone extension cord). The customer should be aware that compliance with the above conditions may not prevent degradation of service in some situations.

Repairs to certified equipment should be made by an authorized Canadian maintenance facility designated by the supplier. Any repairs or alterations made by the user to this equipment, or equipment malfunctions, may give the telecommunications company cause to request the user to disconnect the equipment.

Users should ensure for their own protection that the electrical ground connections of the power utility, telephone lines and internal metallic water pipe system (if present) are connected together. This precaution may be particularly important in rural areas.

Caution: Users should not attempt to make such connections themselves, but should contact the appropriate electric inspection authority, or electrician, as appropriate.

WARRANTY AND SERVICE

What does this warranty cover?

This warranty covers any defects in workmanship or materials in this product purchased in the U.S. or Canada. For warranty information in other countries, contact your local distributor.

How long does the coverage last?

This warranty runs for one year from the date of purchase.

What will Plantronics do?

If the product is found defective, we will replace it at no charge.

What does this warranty NOT cover?

Damage caused by accident, abuse, misuse, or an act of God (such as a flood) are not covered. Implied warranties, including those of merchantability, fitness for a particular purpose and non-infringement shall (a) have no duration greater than one year from the date of purchase, (b) terminate automatically at the end of that period, and (c) to the extent permitted by law, be excluded. Consequential and incidental damages, including without limitation, loss of property and those arising from breach of any express or implied warranty, are not the responsibility of Plantronics, and to the extent permitted by law, are excluded. Some states do not allow exclusion or limitation of incidental or consequential damages, so the above exclusion may not apply to you.

How do you get service?


To obtain service in the U.S. contact Plantronics at (800) 544-4660 and in Canada call (800) 540-8363.

How does state law apply?


This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

EXAMINE THE COMPONENTS OF THE CS50 SYSTEM


BASE & CHARGING UNIT



CORDLESS HEADSET



WEARING OPTIONS



CS50 WIRELESS OFFICE HEADSET SYSTEM

This Quick Start Guide and the Product Information Booklet are located on our website at www.plantronics.com/documentation/. Choose your language preference and Plantronics model number.

1 Set Up the Base


1.1 Connect your telephone's handset cord to the handset jack.

1.2 Connect your telephone with the supplied short cord (25) to the telephone base jack.

1.3 Connect the supplied AC power adapter to the AC power adapter jack and the plug into your power source.

The red power indicator light (3) should go on.

1.4 Connect the *(optional) Handset Lifter to the accessory jack and attach to telephone per handset lifter instructions.




2 Charge the Headset

2.1 Dock the headset into the charge cradle (1). The amber charge indicator (9) will flash during charge.

If charge indicator does not go on, re-position headset in the cradle.

2.2 The charge indicator will go steady after headset is fully charged and ready for use (approximately 3 hours).



3 Set Up the Headset For over-the-head use

3.1 Determine right or left ear wearing position and snap the headset speaker capsule (20) into the t-pad headset retainer ring.

3.2 While wearing the headset, adjust the microphone tip toward the corner of your mouth by rotating the speaker capsule within the t-pad retainer ring.

You may need to support the headband in position while doing this, or just take off headset and adjust, as the fit is snug.

OR


For over-the-ear use

3.3 Choose the earloop (21) size (small, medium, or large) that should best fit your ear. (You may need to experiment to find the best comfort).

3.4 Determine right or left ear wearing position and snap the headset speaker capsule into the earloop ring accordingly.

3.5 While wearing the headset, adjust the microphone tip toward the corner of your mouth by rotating the speaker capsule within the earloop retainer ring.

You may need to support the earloop in position while doing this, or just take off headset and adjust, as the fit is snug.



4 Setup and Test Your System

4.1 Begin with your "charged" headset mounted in the configuration of your choice.

4.2 Remove the telephone handset from its base, taking it "off-hook".


4.3 Press the talk button on the headset.

The talk indicator lights on both the base (2) and headset (17) should go on, indicating a successful link. You should now be able to hear a dial tone through the headset.

4.4 If not, you need to adjust your telephone configuration dial (4) on the base to another one of its 4 positions until you hear the tone.

4.5 Continue configuration setup by making a test call to a friend or associate using the key pad on your telephone.

4.6 If they cannot hear you at all try changing your telephone configuration dial on the base to another one of its 4 positions until you hear them and they hear you. Volume adjustments can be made separately as described in the next step.



5 Make Volume and Final Adjustments

5.1 Adjust your listening volume with the listen volume control (15) dial located towards the back of the headset capsule. Rock the dial up or down for volume changes.

5.2 For "larger step" adjustments to your listening volume, change the position setting on the listen volume master switch located on the back of the base.

5.3 Push in the mute control (15) to activate mute, push in again to de-activate mute. (You will hear a slight beep in the speaker when mute is activated.)

5.4 Adjust your speak volume (how others hear you) with the speak volume fine tune (13) buttons on the back side of the base.

5.5 For "larger step" adjustments to your speak volume, change the position setting on the talk volume master (12) switch located on the bottom of the base.

5.6 You can now activate your IntelliStand feature if you have installed the optional handset lifter. When enabled, this feature provides automatic Lifter activation by simply removing and replacing your headset in the base unit (no need to press the talk button on the headset).

To enable, slide the IntelliStand switch located on the side of the base to the on position (down) or disable by sliding to the off position (up).

