

# QUICK START GUIDE



## CHARGE 4




## WHAT'S IN THE BOX




## BLUETOOTH PAIRING



## PLAY



## CONNECT +




## CHARGE



To preserve battery lifespan, fully charge at least once every 45 days.

## ~~RECHARGE~~



## WATERPROOF IPX7



Ensure the cap is well sealed before exposing to liquids.

## WARNING !



