



E25BT




E25BT

Quick Start Guide
Guide de démarrage rapide

1 What's in the box

E25BT




x 1

Charging cable



x 1

Ear tips



x 4

Clip



x 1

Carrying Pouch, Warranty card, QSG, Warning card image





E25BT

Quick Start Guide


Guide de démarrage rapide

2 Overview – Buttons & LEDs

1. Buttons and LED's



2. Connection




E25BT


Quick Start Guide
Guide de démarrage rapide

3 Wear the headphone


1. Select the right ear tips



2. Wear behind the neck



3.



* Use when you want to fix the headphone


E25BT

Quick Start Guide Guide de démarrage rapide


4 Bluetooth connection

1. Bluetooth

a. Connecting device



b. Connecting 2nd device



EN

Device mode	Bluetooth LED	
	Blue	Flash
Power on + No BT Connected	Yes	Slow
Power on + BT Pairing	Yes	Fast
Power on + BT Connected	Yes	On

FR

Device mode	Bluetooth LED	
	Blue	Flash
Power on + No BT Connected	Yes	Slow
Power on + BT Pairing	Yes	Fast
Power on + BT Connected	Yes	On

ES

Device mode	Bluetooth LED	
	Blue	Flash
Power on + No BT Connected	Yes	Slow
Power on + BT Pairing	Yes	Fast
Power on + BT Connected	Yes	On

DE

Device mode	Bluetooth LED	
	Blue	Flash
Power on + No BT Connected	Yes	Slow
Power on + BT Pairing	Yes	Fast
Power on + BT Connected	Yes	On

E25BT

Quick Start Guide Guide de démarrage rapide

IT

Device mode	Bluetooth LED	
	Blue	Flash
Power on + No BT Connected	Yes	 Slow
Power on + BT Pairing	Yes	 Fast
Power on + BT Connected	Yes	 On

NL

Device mode	Bluetooth LED	
	Blue	Flash
Power on + No BT Connected	Yes	 Slow
Power on + BT Pairing	Yes	 Fast
Power on + BT Connected	Yes	 On

NO

Device mode	Bluetooth LED	
	Blue	Flash
Power on + No BT Connected	Yes	 Slow
Power on + BT Pairing	Yes	 Fast
Power on + BT Connected	Yes	 On

FI

Device mode	Bluetooth LED	
	Blue	Flash
Power on + No BT Connected	Yes	 Slow
Power on + BT Pairing	Yes	 Fast
Power on + BT Connected	Yes	 On

SV

Device mode	Bluetooth LED	
	Blue	Flash
Power on + No BT Connected	Yes	 Slow
Power on + BT Pairing	Yes	 Fast
Power on + BT Connected	Yes	 On

DA

Device mode	Bluetooth LED	
	Blue	Flash
Power on + No BT Connected	Yes	 Slow
Power on + BT Pairing	Yes	 Fast
Power on + BT Connected	Yes	 On

PO

Device mode	Bluetooth LED	
	Blue	Flash
Power on + No BT Connected	Yes	 Slow
Power on + BT Pairing	Yes	 Fast
Power on + BT Connected	Yes	 On

HU

Device mode	Bluetooth LED	
	Blue	Flash
Power on + No BT Connected	Yes	 Slow
Power on + BT Pairing	Yes	 Fast
Power on + BT Connected	Yes	 On

RU

Device mode	Bluetooth LED	
	Blue	Flash
Power on + No BT Connected	Yes	 Slow
Power on + BT Pairing	Yes	 Fast
Power on + BT Connected	Yes	 On

PT

Device mode	Bluetooth LED	
	Blue	Flash
Power on + No BT Connected	Yes	 Slow
Power on + BT Pairing	Yes	 Fast
Power on + BT Connected	Yes	 On

ID

Device mode	Bluetooth LED	
	Blue	Flash
Power on + No BT Connected	Yes	 Slow
Power on + BT Pairing	Yes	 Fast
Power on + BT Connected	Yes	 On

JP

Device mode	Bluetooth LED	
	Blue	Flash
Power on + No BT Connected	Yes	 Slow
Power on + BT Pairing	Yes	 Fast
Power on + BT Connected	Yes	 On

E25BT

Quick Start Guide Guide de démarrage rapide

KO

Device mode	Bluetooth LED	
	Blue	Flash
Power on + No BT Connected	Yes	Slow
Power on + BT Pairing	Yes	Fast
Power on + BT Connected	Yes	On

CHS

Device mode	Bluetooth LED	
	Blue	Flash
Power on + No BT Connected	Yes	Slow
Power on + BT Pairing	Yes	Fast
Power on + BT Connected	Yes	On

CHT

Device mode	Bluetooth LED	
	Blue	Flash
Power on + No BT Connected	Yes	Slow
Power on + BT Pairing	Yes	Fast
Power on + BT Connected	Yes	On



HE

Device mode	Bluetooth LED	
	Blue	Flash
Power on + No BT Connected	Yes	Slow
Power on + BT Pairing	Yes	Fast
Power on + BT Connected	Yes	On

AR

Device mode	Bluetooth LED	
	Blue	Flash
Power on + No BT Connected	Yes	Slow
Power on + BT Pairing	Yes	Fast
Power on + BT Connected	Yes	On

5 Music control




E25BT


Quick Start Guide

Guide de démarrage rapide

6 Phone call



7 Charging



E25BT

Quick Start Guide Guide de démarrage rapide

8 LED behaviour



EN

Device mode	Bluetooth LED	
	White	Flash
ⓘ Power on	Yes	Fast
ⓘ Power off	Yes	Fast
🔋 Lower battery + No BT Connected	Yes	Slow
🔋 Lower battery + BT Pairing	Yes	Slow
🔋 Lower battery + BT Connected	Yes	Slow
🔋 Charging Complete	No	N/A
🔋 Charging Complete	Yes	On

FR

Device mode	Bluetooth LED	
	White	Flash
ⓘ Power on	Yes	Fast
ⓘ Power off	Yes	Fast
🔋 Lower battery + No BT Connected	Yes	Slow
🔋 Lower battery + BT Pairing	Yes	Slow
🔋 Lower battery + BT Connected	Yes	Slow
🔋 Charging Complete	No	N/A
🔋 Charging Complete	Yes	On

ES

Device mode	Bluetooth LED	
	White	Flash
ⓘ Power on	Yes	Fast
ⓘ Power off	Yes	Fast
🔋 Lower battery + No BT Connected	Yes	Slow
🔋 Lower battery + BT Pairing	Yes	Slow
🔋 Lower battery + BT Connected	Yes	Slow
🔋 Charging Complete	No	N/A
🔋 Charging Complete	Yes	On

DE

Device mode	Bluetooth LED	
	White	Flash
ⓘ Power on	Yes	Fast
ⓘ Power off	Yes	Fast
🔋 Lower battery + No BT Connected	Yes	Slow
🔋 Lower battery + BT Pairing	Yes	Slow
🔋 Lower battery + BT Connected	Yes	Slow
🔋 Charging Complete	No	N/A
🔋 Charging Complete	Yes	On

IT

Device mode	Bluetooth LED	
	White	Flash
ⓘ Power on	Yes	Fast
ⓘ Power off	Yes	Fast
🔋 Lower battery + No BT Connected	Yes	Slow
🔋 Lower battery + BT Pairing	Yes	Slow
🔋 Lower battery + BT Connected	Yes	Slow
🔋 Charging Complete	No	N/A
🔋 Charging Complete	Yes	On

NL

Device mode	Bluetooth LED	
	White	Flash
ⓘ Power on	Yes	Fast
ⓘ Power off	Yes	Fast
🔋 Lower battery + No BT Connected	Yes	Slow
🔋 Lower battery + BT Pairing	Yes	Slow
🔋 Lower battery + BT Connected	Yes	Slow
🔋 Charging Complete	No	N/A
🔋 Charging Complete	Yes	On

E25BT

Quick Start Guide Guide de démarrage rapide

NO

Device mode	Bluetooth LED	
	White	Flash
Ⓜ Power on	Yes	Fast
Ⓜ Power off	Yes	Fast
🔋 Lower battery + BT Connected	Yes	Slow
🔋 Lower battery + BT Charging	Yes	Slow
🔋 Lower battery + BT Connected	Yes	Slow
🔋 Charging Complete	No	N/A
🔋 Charging Complete	Yes	On

FI

Device mode	Bluetooth LED	
	White	Flash
Ⓜ Power on	Yes	Fast
Ⓜ Power off	Yes	Fast
🔋 Lower battery + BT Connected	Yes	Slow
🔋 Lower battery + BT Charging	Yes	Slow
🔋 Lower battery + BT Connected	Yes	Slow
🔋 Charging Complete	No	N/A
🔋 Charging Complete	Yes	On

SV

Device mode	Bluetooth LED	
	White	Flash
Ⓜ Power on	Yes	Fast
Ⓜ Power off	Yes	Fast
🔋 Lower battery + BT Connected	Yes	Slow
🔋 Lower battery + BT Charging	Yes	Slow
🔋 Lower battery + BT Connected	Yes	Slow
🔋 Charging Complete	No	N/A
🔋 Charging Complete	Yes	On

DA

Device mode	Bluetooth LED	
	White	Flash
Ⓜ Power on	Yes	Fast
Ⓜ Power off	Yes	Fast
🔋 Lower battery + BT Connected	Yes	Slow
🔋 Lower battery + BT Charging	Yes	Slow
🔋 Lower battery + BT Connected	Yes	Slow
🔋 Charging Complete	No	N/A
🔋 Charging Complete	Yes	On

PO

Device mode	Bluetooth LED	
	White	Flash
Ⓜ Power on	Yes	Fast
Ⓜ Power off	Yes	Fast
🔋 Lower battery + BT Connected	Yes	Slow
🔋 Lower battery + BT Charging	Yes	Slow
🔋 Lower battery + BT Connected	Yes	Slow
🔋 Charging Complete	No	N/A
🔋 Charging Complete	Yes	On

HU

Device mode	Bluetooth LED	
	White	Flash
Ⓜ Power on	Yes	Fast
Ⓜ Power off	Yes	Fast
🔋 Lower battery + BT Connected	Yes	Slow
🔋 Lower battery + BT Charging	Yes	Slow
🔋 Lower battery + BT Connected	Yes	Slow
🔋 Charging Complete	No	N/A
🔋 Charging Complete	Yes	On

RU

Device mode	Bluetooth LED	
	White	Flash
Ⓜ Power on	Yes	Fast
Ⓜ Power off	Yes	Fast
🔋 Lower battery + BT Connected	Yes	Slow
🔋 Lower battery + BT Charging	Yes	Slow
🔋 Lower battery + BT Connected	Yes	Slow
🔋 Charging Complete	No	N/A
🔋 Charging Complete	Yes	On

PT

Device mode	Bluetooth LED	
	White	Flash
Ⓜ Power on	Yes	Fast
Ⓜ Power off	Yes	Fast
🔋 Lower battery + BT Connected	Yes	Slow
🔋 Lower battery + BT Charging	Yes	Slow
🔋 Lower battery + BT Connected	Yes	Slow
🔋 Charging Complete	No	N/A
🔋 Charging Complete	Yes	On

E25BT

Quick Start Guide Guide de démarrage rapide

ID

Device mode	Bluetooth LED	
	White	Flash
Ⓜ Power on	Yes	Fast
Ⓜ Power off	Yes	Fast
🔋 Lower battery + BT Connected	Yes	Slow
🔋 Lower battery + BT Charging	Yes	Slow
🔋 Lower battery + BT Connected	Yes	Slow
🔋 Charging Complete	No	N/A
🔋 Charging Complete	Yes	On

JP

Device mode	Bluetooth LED	
	White	Flash
Ⓜ Power on	Yes	Fast
Ⓜ Power off	Yes	Fast
🔋 Lower battery + BT Connected	Yes	Slow
🔋 Lower battery + BT Charging	Yes	Slow
🔋 Lower battery + BT Connected	Yes	Slow
🔋 Charging Complete	No	N/A
🔋 Charging Complete	Yes	On

KO

Device mode	Bluetooth LED	
	White	Flash
Ⓜ Power on	Yes	Fast
Ⓜ Power off	Yes	Fast
🔋 Lower battery + BT Connected	Yes	Slow
🔋 Lower battery + BT Charging	Yes	Slow
🔋 Lower battery + BT Connected	Yes	Slow
🔋 Charging Complete	No	N/A
🔋 Charging Complete	Yes	On

CHS

Device mode	Bluetooth LED	
	White	Flash
Ⓜ Power on	Yes	Fast
Ⓜ Power off	Yes	Fast
🔋 Lower battery + BT Connected	Yes	Slow
🔋 Lower battery + BT Charging	Yes	Slow
🔋 Lower battery + BT Connected	Yes	Slow
🔋 Charging Complete	No	N/A
🔋 Charging Complete	Yes	On

CHT

Device mode	Bluetooth LED	
	White	Flash
Ⓜ Power on	Yes	Fast
Ⓜ Power off	Yes	Fast
🔋 Lower battery + BT Connected	Yes	Slow
🔋 Lower battery + BT Charging	Yes	Slow
🔋 Lower battery + BT Connected	Yes	Slow
🔋 Charging Complete	No	N/A
🔋 Charging Complete	Yes	On

HE

Device mode	Bluetooth LED	
	White	Flash
Ⓜ Power on	Yes	Fast
Ⓜ Power off	Yes	Fast
🔋 Lower battery + BT Connected	Yes	Slow
🔋 Lower battery + BT Charging	Yes	Slow
🔋 Lower battery + BT Connected	Yes	Slow
🔋 Charging Complete	No	N/A
🔋 Charging Complete	Yes	On

AR

Device mode	Bluetooth LED	
	White	Flash
Ⓜ Power on	Yes	Fast
Ⓜ Power off	Yes	Fast
🔋 Lower battery + BT Connected	Yes	Slow
🔋 Lower battery + BT Charging	Yes	Slow
🔋 Lower battery + BT Connected	Yes	Slow
🔋 Charging Complete	No	N/A
🔋 Charging Complete	Yes	On

E25BT

Quick Start Guide

Guide de démarrage rapide



Specifications

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

E25BT

Quick Start Guide Guide de démarrage rapide

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

E25BT

Quick Start Guide Guide de démarrage rapide

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth range
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth range
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth range
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth range
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth range
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

E25BT

Quick Start Guide Guide de démarrage rapide

Торговая марка: JBL
Назначение товара: Пользовательские наушники
Изготовитель: Харман Интернешнл Индастриз Инкорпорейтед, США, 06901 Коннектикут, г.Стэмфорд, Атлантик Стрит 400, офис 1500
Страна происхождения: Китай
Импортер в Россию: ООО "ХАРМАН РУС" "АйЭс", РОССИЯ, 127018, г.МОСКВА, УЛ. ДВИНЦЕВ, Д.12, КОРПУС 1
Гарантийный период: 1 год
Информация о сервисных центрах: www.harman.com/ru тел. +7-800-700-0467
Срок службы: 2 года
Срок хранения: не ограничен
Условия хранения: Стандартные при нормальных значениях климатических факторов внешней среды
Номер документа соответствия: Товар не подлежит обязательной сертификации
Дата производства: Дата изготовления устройства определяется по двум буквенным обозначениям из второй группы символов серийного номера изделия, следующих после разделительного знака. Кодировка соответствует порядку букв латинского алфавита, начиная с января 2010 года. 0000000-MY00000000, где «М» - месяц производства (А - январь, В - февраль, С - март и т.д.) и «У» - год производства (А - 2010, В - 2011, С - 2012 и т.д.).

А	2010	А	2010
В	2011	В	2011
С	2012	С	2012
Д	2013	Д	2013
Е	2014	Е	2014
Ж	2015	Ж	2015
З	2016	З	2016
И	2017	И	2017
Й	2018	Й	2018
К	2019	К	2019
Л	2020	Л	2020
М	2021	М	2021
Н	2022	Н	2022
О	2023	О	2023
П	2024	П	2024
Р	2025	Р	2025
С	2026	С	2026
Т	2027	Т	2027
У	2028	У	2028
Ф	2029	Ф	2029
Х	2030	Х	2030
Ц	2031	Ц	2031
Ч	2032	Ч	2032
Ш	2033	Ш	2033
Щ	2034	Щ	2034
Ъ	2035	Ъ	2035
Ы	2036	Ы	2036
Ь	2037	Ь	2037
Э	2038	Э	2038
Ю	2039	Ю	2039
Я	2040	Я	2040

E25BT

Quick Start Guide

Guide de démarrage rapide

Este equipamento opera em caráter secundário, isto é, não tem direito a proteção contra interferência prejudicial, mesmo de estações do mesmo tipo, e não pode causar interferência a sistemas operando em caráter primário"

Este produto está homologado pela ANATEL, de acordo com os procedimentos regulamentados pela Resolução 242/2000, e atende aos requisitos técnicos aplicados.

Para maiores informações, consulte o site da ANATEL - www.anatel.gov.br



Agência Nacional de Telecomunicações

3817-15-7130



(01)07896359541133



The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by HARMAN International Industries, Incorporated is under license. Other trademarks and trade names are those of their respective owners.