



E45BT / E55BT



E45BT / E55BT

Quick Start Guide
Guide de démarrage rapide


1 What's in the box

E45BT / E55BT x 1




x1

Charging cable x 1




x1

Detachable audio cable x 1



x1

Warranty card, QSG, Warning card



x1

E45BT / E55BT

Quick Start Guide
Guide de démarrage rapide

2 Overview - Buttons & LEDs

a. Buttons & LEDs



b. Connections



E45BT / E55BT

Quick Start Guide Guide de démarrage rapide

3 Bluetooth Connection

a. To turn on the headphone




b. For the first time connection the headphone will enter pair mode automatically 5 secs after power on

c. Connect via devices

d. Press bluetooth button to pair and connect with the device.

1) Bluetooth paring for 1st device




E45BT / E55BT


Quick Start Guide

Guide de démarrage rapide

2) Bluetooth pairing for 2nd device



3) Go back to the bluetooth device list on the 1st device and click connect



E45BT / E55BT


Quick Start Guide Guide de démarrage rapide

4 Music play


1) To turn on Bluetooth to pair



2) To pair Bluetooth with the device



Choose "JBL E45BT" to connect



Choose "JBL E55BT" to connect



E45BT / E55BT

Quick Start Guide

Guide de démarrage rapide


3) Music control



E45BT / E55BT

Quick Start Guide Guide de démarrage rapide

5 Phone call



Press

Hang up current call and
switch to second call



Switch calls

Long Press

6 Passive listening mode

- 1) Use the headphone with wire
- 2) 2nd device will be the main source of music and movie.
- 3) If you want to change the 1st device to be the main source, stop the music/movie on 2nd device, start the music/movie on the 1st device.
- 4) If there is phone call from either devices, phone call will take the 1st priority
- 5) There are maximum 2 devices can be connected at the same time.

E45BT / E55BT

Quick Start Guide
Guide de démarrage rapide

7 LED behaviour



Device mode	Power/ BT LED			Charging LED	
	White	Blue	Flash	Red	Flash
Power on + No BT Connected	YES	NO	Solid On	NO	N/A
Power on + BT Pairing	NO	YES	P5	NO	N/A
Power on + BT Connected	NO	YES	Solid On	NO	N/A
Lower battery + No BT Connected	NO	NO	N/A	YES	P2
Lower battery + BT Pairing	NO	NO	N/A	YES	P2
Lower battery + BT Connected	NO	NO	N/A	YES	P2
Charging Complete	NO	NO	N/A	NO	N/A
Charging in Progress	NO	NO	N/A	YES	Solid On
FW Version LED display*	NO	NO	N/A	YES	P3

E45BT / E55BT

Quick Start Guide

Guide de démarrage rapide

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

E45BT / E55BT

Quick Start Guide

Guide de démarrage rapide

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

E45BT / E55BT

Quick Start Guide

Guide de démarrage rapide

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

EN

- Driver size
- Dynamic frequency response range
- Driver sensitivity
- Maximum SPL
- Bluetooth spec
- Battery type
- Charging time
- Music play time with BT on
- Dimension W x H x L (mm)
- Weight (kg)

E45BT / E55BT

Quick Start Guide

Guide de démarrage rapide

Торговая марка: JBL

Назначение товара: Пользовательские наушники

Изготовитель: Харман Интернешнл Индастриз Инкорпорейтед, США, 06901 Коннектикут, г.Стэмфорд, Атлантик Стрит 400, офис 1500

Страна происхождения: Китай

Импортёр в Россию: ООО "ХАРМАН РУС СиАйЭс", РОССИЯ, 127018, г.МОСКВА, УЛ. ДВИНЦЕВ, Д.12, КОРПУС 1

Гарантийный период: 1 год

Информация о сервисных центрах: www.harman.com/ru тел. +7-800-700-0467

Срок службы: 2 года

Товар не подлежит обязательной сертификации

Дата производства: Дата изготовления устройства определяется по двум буквенным обозначениям из второй группы символов серийного номера изделия, следующих после разделительного знака «-». Кодировка соответствует порядку букв латинского алфавита, начиная с января 2010 года: 000000-MY00000000, где «М» - месяц производства (А - январь, В - февраль, С - март и т.д.) и «Y» - год производства (А - 2010, В - 2011, С - 2012 и т.д.).

Este equipamento opera em caráter secundário, isto é, não tem direito a proteção contra interferência prejudicial, mesmo de estações do mesmo tipo, e não pode causar interferência a sistemas operando em caráter primário"

Este produto está homologado pela ANATEL, de acordo com os procedimentos regulamentados pela Resolução 242/2000, e atende aos requisitos técnicos aplicados.

Para maiores informações, consulte o site da ANATEL - www.anatel.gov.br



3817-15-7120



(01)07896359541133



The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by HARMAN International Industries, Incorporated is under license. Other trademarks and trade names are those of their respective owners.

RESTRICTED

DESIGN ADAPTATION / IMAGE / FINAL ART

TR & Job No: TR02171
Job Description: TR02171_JBL_E4S8T+E5S8T_QSG_A
Version : 2
Date: 2016-08-05
Other: N/A



Developed by
SARAH/08/03

EQUITY COLORS: REPRESENTATION:



IMPORTANT NOTE : THE PRINT/PDF IS FOR LAYOUT AND TEXT ILLUSTRATION ONLY. THE COLOURS INDICATED HERE MAY NOT APPEAR SAME IN THE FINAL PROOF. ALTHOUGH EVERY EFFORT HAS BEEN MADE TO CHECK THE CORRECTION OF LAYOUT AND TEXT. IT IS CLIENT RESPONSIBILITY TO VERIFY BEFORE GIVING THE FINAL APPROVAL.