




**FLIP4 J**

Quick Start Guide  
Guide de démarrage rapide

① What's in the box



② Buttons



Quick Start Guide  
Guide de démarrage rapide




Choose "JBL Flip 4" to connect



Quick Start Guide  
Guide de démarrage rapide


—



1. Download Bluetooth Com

[illegible]

Quick Start Guide  
Guide de démarrage rapide

[illegible]

Quick Start Guide  
Guide de démarrage rapide

**Step 1**

Diagram illustrating the connection of a smartphone to Speaker A. The smartphone is connected to Speaker A via a cable.

**Step 2**

Diagram illustrating the connection of Speaker A to Speaker B, and then Speaker B to Speaker C. Speaker A is connected to Speaker B, which is then connected to Speaker C.

Quick Start Guide  
Guide de démarrage rapide

### Step 3

[illegible]


Quick Start Guide  
Gukle de démarrage rapide

## Play music

[illegible]

Quick Start Guide  
Guide de démarrage rapide

**8 Warning**



**IMPORTANT:** To ensure that the JBL Flip 4 is water-tight, please remove all cables connections and tightly close the cap, exposing the JBL Flip 4 to water. After doing so may result in permanent damage to the speaker. And do not expose the JBL Flip 4 to water while charging, as doing so may result in permanent damage to the speaker or other devices.

**IMPORTANT:** To ensure that the JBL Flip 4 is water-tight, please remove all cables connections and tightly close the cap, exposing the JBL Flip 4 to water. If the cap is not closing so may result in permanent damage to the speaker. And do not expose the Flip 4 to water while charging, as doing so may result in permanent damage to the speaker or its cables.

**IMPORTANT:** To ensure that the JBL Flip 4 is waterproof, please remove all cables connections and tightly close the cap, exposing the JBL Flip 4 to liquids without doing so may result in permanent damage to the speaker. And do not expose JBL Flip 4 to water while charging, as doing so may result in permanent damage to the speaker or power source.

**IMPORTANT:** To ensure that the JBL Flip 4 is waterproof, please remove all cables connections and tightly close the cap; exposing the JBL Flip 4 to liquids without doing so may result in permanent

Quick Start Guide  
Gukle de démarrage rapide

JBL Flip 4 is IPX7 waterproof; submersion in water or other liquids may result in permanent damage to the speaker.

**IMPORTANT:** To ensure that the JBL Flip 4 is waterproof, please remove all cables connections and tightly close the cap; exposing the Flip 4 to water without doing so may result in permanent damage to the speaker. And do not use JBL Flip 4 to water while charging, as doing so may result in permanent damage to the speaker or power source.

**IPX7 waterproof** is defined as the speaker can be immersed in water up to 1 m for up to 30 minutes.

© 2015 JBL Inc. JBL7 is a registered trademark of JBL Inc. All other trademarks are the property of their respective owners.

**IMPORTANT:** To ensure that the JBL Flip 4 is properly sealed, please remove all cables connections and tightly close the cap; exposing the JBL Flip 4 to water without doing so may result in permanent damage to the speaker. And do not expose the cap if it is water while charging, as doing so may result in permanent damage to the speaker's power source.

**IPX7 waterproof:** defined as the device can be immersed in water up to 1m for up to 30 minutes.

**IMPORTANT:** To ensure that the JBL Flip 4 is waterproof, please remove all cables connections and tightly close the cap; exposing the JBL Flip 4 to liquid or immersing it so may result in permanent damage to the speaker. And do not expose JBL Flip 4 to water while charging, as doing so may result in permanent damage to the speaker or power source.

**IMPORTANT:** To ensure that the JBL Flip 4 is waterproof, please remove all cables connections and tightly close the cap; exposing the JBL Flip 4 to liquids without doing so may result in permanent damage to the speakers. And do not expose JBL Flip 4 to water while charging, as doing so may result in permanent damage to the speaker.

**IMPORTANT:** To ensure that the JBL Flip 4 is properly sealed, we remove all cables connections and tightly close the cap; exposing the JBL Flip 4 to liquids without doing so may result in permanent

**IMPORTANT:** To ensure that the JBL Flip 4 is waterproof, please remove all cable connections and

JBL Flip 4 is **not** waterproof; submerging it in water or other liquids may result in permanent damage to the speaker.

**IMPORTANT:** To ensure that the JST, H-p 4 is IP67 waterproof, please remove all cable connections and tightly close the cap; exposing the JST, H-p 4 to liquids without doing so may result in permanent damage to the speaker. And do not immerse the JST, H-p 4 in water while charging, as doing so may result in permanent damage to the speaker's power source.

**IP67 waterproof** is defined as the speaker can be immersed in water up to 1m for up to 30 minutes.

JST, H-p 4 is IP67 waterproof; submerging it in water or other liquids may result in permanent damage.