

HEADPHONES WIRELESS



1. SELECT YOUR SIZE

1.1 Two sizes of enhancers are included, the smaller size comes installed.



Size 5



Size 7

1.2 The correct size will fill the bowl of your ear and fit snugly.





* Need help with sizing or support? Contact customer service at **1-(800) 336-4525** or online at **www.jbl.com/under-armour**

2. HOW TO WEAR

- 2.1 Cord should be worn in front position for secure fit and optimal performance.




- 2.2 For behind the neck use, a cinch is included to improve fit. Overtightening the cinch will dislodge buds.




3. ATTACH ENHANCERS

- 3.1 Align sound tunnels and gently stretch the enhancer edges as needed.




- 3.2 Insert earphones into ear and twist into place. Adjust for comfort.




4. PAIR/POWER/CHARGE

4.1 Begin with the unit powered off and your Bluetooth device powered on and in search mode.




4.2 Charging Port & Battery Status




5. 3-BUTTON COMMAND


5.1 Music Control



5.2 Phone Control



5.3 Volume Control



FRANÇAIS

1. Select Your Size: Great sound performance is in selecting the correct size enhancer.
 - 1.1 Two sizes of enhancers are included, the smaller size comes installed. Try both sizes to determine your correct fit.
 - 1.2 The correct size will fit securely in the bowl of your ear. If the buds fall out in use, try the larger size.
 - 1.3 Need help sizing or support? Contact customer service at 1-(800) 336-4525.
2. How To Wear:
 - 2.1 To optimize performance and get the most secure fit during your workout, cord should be worn in front position.
 - 2.2 For behind the neck use, a cinch is included to improve fit. Adjust the cinch so cord is off your neck but not tight enough that buds pull.
3. Attach Enhancers:
 - 3.1 Install enhancer to earbud by aligning the sound tunnels and gently stretching the enhancer edges as needed.
4. Power/Pair/Charge:
 - 4.1 Power On/Off:
 -  Power On
 -  Power Off
 - 4.2 Pair & Sync:
 -  Pairing Mode
 -  Connected
 - 4.3 Charging Port & Battery Status:
 -  Low Battery
5. 3-Button Command
 - 5.1 Music Control
 - 5.2 Phone Control
 - 5.3 Volume Control

PORTUGUÊS

1. Select Your Size: Great sound performance is in selecting the correct size enhancer.
 - 1.1 Two sizes of enhancers are included, the smaller size comes installed. Try both sizes to determine your correct fit.
 - 1.2 The correct size will fit securely in the bowl of your ear. If the buds fall out in use, try the larger size.
 - 1.3 Need help sizing or support? Contact customer service at 1-(800) 336-4525.
2. How To Wear:
 - 2.1 To optimize performance and get the most secure fit during your workout, cord should be worn in front position.
 - 2.2 For behind the neck use, a cinch is included to improve fit. Adjust the cinch so cord is off your neck but not tight enough that buds pull.
3. Attach Enhancers:
 - 3.1 Install enhancer to earbud by aligning the sound tunnels and gently stretching the enhancer edges as needed.
4. Power/Pair/Charge:
 - 4.1 Power On/Off:
 -  Power On
 -  Power Off
 - 4.2 Pair & Sync:
 -  Pairing Mode
 -  Connected
 - 4.3 Charging Port & Battery Status:
 -  Low Battery
5. 3-Button Command
 - 5.1 Music Control
 - 5.2 Phone Control
 - 5.3 Volume Control

简体中文

1. Select Your Size: Great sound performance is in selecting the correct size enhancer.
 - 1.1 Two sizes of enhancers are included, the smaller size comes installed. Try both sizes to determine your correct fit.
 - 1.2 The correct size will fit securely in the bowl of your ear. If the buds fall out in use, try the larger size.
 - 1.3 Need help sizing or support? Contact customer service at 1-(800) 336-4525.
2. How To Wear:
 - 2.1 To optimize performance and get the most secure fit during your workout, cord should be worn in front position.
 - 2.2 For behind the neck use, a cinch is included to improve fit. Adjust the cinch so cord is off your neck but not tight enough that buds pull.
3. Attach Enhancers:
 - 3.1 Install enhancer to earbud by aligning the sound tunnels and gently stretching the enhancer edges as needed.
4. Power/Pair/Charge:
 - 4.1 Power On/Off:
 -  Power On
 -  Power Off
 - 4.2 Pair & Sync:
 -  Pairing Mode
 -  Connected
 - 4.3 Charging Port & Battery Status:
 -  Low Battery
5. 3-Button Command
 - 5.1 Music Control
 - 5.2 Phone Control
 - 5.3 Volume Control

ESPAÑOL

1. Select Your Size: Great sound performance is in selecting the correct size enhancer.
 - 1.1 Two sizes of enhancers are included, the smaller size comes installed. Try both sizes to determine your correct fit.
 - 1.2 The correct size will fit securely in the bowl of your ear. If the buds fall out in use, try the larger size.
 - 1.3 Need help sizing or support? Contact customer service at 1-(800) 336-4525.
2. How To Wear:
 - 2.1 To optimize performance and get the most secure fit during your workout, cord should be worn in front position.
 - 2.2 For behind the neck use, a cinch is included to improve fit. Adjust the cinch so cord is off your neck but not tight enough that buds pull.
3. Attach Enhancers:
 - 3.1 Install enhancer to earbud by aligning the sound tunnels and gently stretching the enhancer edges as needed.
4. Power/Pair/Charge:
 - 4.1 Power On/Off:
 -  Power On
 -  Power Off
 - 4.2 Pair & Sync:
 -  Pairing Mode
 -  Connected
 - 4.3 Charging Port & Battery Status:
 -  Low Battery
5. 3-Button Command
 - 5.1 Music Control
 - 5.2 Phone Control
 - 5.3 Volume Control

DEUTSCH

1. Select Your Size: Great sound performance is in selecting the correct size enhancer.
 - 1.1 Two sizes of enhancers are included, the smaller size comes installed. Try both sizes to determine your correct fit.
 - 1.2 The correct size will fit securely in the bowl of your ear. If the buds fall out in use, try the larger size.
 - 1.3 Need help sizing or support? Contact customer service at 1-(800) 336-4525.
2. How To Wear:
 - 2.1 To optimize performance and get the most secure fit during your workout, cord should be worn in front position.
 - 2.2 For behind the neck use, a cinch is included to improve fit. Adjust the cinch so cord is off your neck but not tight enough that buds pull.
3. Attach Enhancers:
 - 3.1 Install enhancer to earbud by aligning the sound tunnels and gently stretching the enhancer edges as needed.
4. Power/Pair/Charge:
 - 4.1 Power On/Off:
 -  Power On
 -  Power Off
 - 4.2 Pair & Sync:
 -  Pairing Mode
 -  Connected
 - 4.3 Charging Port & Battery Status:
 -  Low Battery
5. 3-Button Command
 - 5.1 Music Control
 - 5.2 Phone Control
 - 5.3 Volume Control

ITALIANO

1. Select Your Size: Great sound performance is in selecting the correct size enhancer.
 - 1.1 Two sizes of enhancers are included, the smaller size comes installed. Try both sizes to determine your correct fit.
 - 1.2 The correct size will fit securely in the bowl of your ear. If the buds fall out in use, try the larger size.
 - 1.3 Need help sizing or support? Contact customer service at 1-(800) 336-4525.
2. How To Wear:
 - 2.1 To optimize performance and get the most secure fit during your workout, cord should be worn in front position.
 - 2.2 For behind the neck use, a cinch is included to improve fit. Adjust the cinch so cord is off your neck but not tight enough that buds pull.
3. Attach Enhancers:
 - 3.1 Install enhancer to earbud by aligning the sound tunnels and gently stretching the enhancer edges as needed.
4. Power/Pair/Charge:
 - 4.1 Power On/Off:
 -  Power On
 -  Power Off
 - 4.2 Pair & Sync:
 -  Pairing Mode
 -  Connected
 - 4.3 Charging Port & Battery Status:
 -  Low Battery
5. 3-Button Command
 - 5.1 Music Control
 - 5.2 Phone Control
 - 5.3 Volume Control

SUOMI

1. Select Your Size: Great sound performance is in selecting the correct size enhancer.
 - 1.1 Two sizes of enhancers are included, the smaller size comes installed. Try both sizes to determine your correct fit.
 - 1.2 The correct size will fit securely in the bowl of your ear. If the buds fall out in use, try the larger size.
 - 1.3 Need help sizing or support? Contact customer service at 1-(800) 336-4525.
2. How To Wear:
 - 2.1 To optimize performance and get the most secure fit during your workout, cord should be worn in front position.
 - 2.2 For behind the neck use, a cinch is included to improve fit. Adjust the cinch so cord is off your neck but not tight enough that buds pull.
3. Attach Enhancers:
 - 3.1 Install enhancer to earbud by aligning the sound tunnels and gently stretching the enhancer edges as needed.
4. Power/Pair/Charge:
 - 4.1 Power On/Off:
 -  Power On
 -  Power Off
 - 4.2 Pair & Sync:
 -  Pairing Mode
 -  Connected
 - 4.3 Charging Port & Battery Status:
 -  Low Battery
5. 3-Button Command
 - 5.1 Music Control
 - 5.2 Phone Control
 - 5.3 Volume Control

日本語

1. Select Your Size: Great sound performance is in selecting the correct size enhancer.
 - 1.1 Two sizes of enhancers are included, the smaller size comes installed. Try both sizes to determine your correct fit.
 - 1.2 The correct size will fit securely in the bowl of your ear. If the buds fall out in use, try the larger size.
 - 1.3 Need help sizing or support? Contact customer service at 1-(800) 336-4525.
2. How To Wear:
 - 2.1 To optimize performance and get the most secure fit during your workout, cord should be worn in front position.
 - 2.2 For behind the neck use, a cinch is included to improve fit. Adjust the cinch so cord is off your neck but not tight enough that buds pull.
3. Attach Enhancers:
 - 3.1 Install enhancer to earbud by aligning the sound tunnels and gently stretching the enhancer edges as needed.
4. Power/Pair/Charge:
 - 4.1 Power On/Off:
 -  Power On
 -  Power Off
 - 4.2 Pair & Sync:
 -  Pairing Mode
 -  Connected
 - 4.3 Charging Port & Battery Status:
 -  Low Battery
5. 3-Button Command
 - 5.1 Music Control
 - 5.2 Phone Control
 - 5.3 Volume Control

한글

1. Select Your Size: Great sound performance is in selecting the correct size enhancer.
 - 1.1 Two sizes of enhancers are included, the smaller size comes installed. Try both sizes to determine your correct fit.
 - 1.2 The correct size will fit securely in the bowl of your ear. If the buds fall out in use, try the larger size.
 - 1.3 Need help sizing or support? Contact customer service at 1-(800) 336-4525.
2. How To Wear:
 - 2.1 To optimize performance and get the most secure fit during your workout, cord should be worn in front position.
 - 2.2 For behind the neck use, a cinch is included to improve fit. Adjust the cinch so cord is off your neck but not tight enough that buds pull.
3. Attach Enhancers:
 - 3.1 Install enhancer to earbud by aligning the sound tunnels and gently stretching the enhancer edges as needed.
4. Power/Pair/Charge:
 - 4.1 Power On/Off:
 -  Power On
 -  Power Off
 - 4.2 Pair & Sync:
 -  Pairing Mode
 -  Connected
 - 4.3 Charging Port & Battery Status:
 -  Low Battery
5. 3-Button Command
 - 5.1 Music Control
 - 5.2 Phone Control
 - 5.3 Volume Control

NEDERLANDS

1. Select Your Size: Great sound performance is in selecting the correct size enhancer.
 - 1.1 Two sizes of enhancers are included, the smaller size comes installed. Try both sizes to determine your correct fit.
 - 1.2 The correct size will fit securely in the bowl of your ear. If the buds fall out in use, try the larger size.
 - 1.3 Need help sizing or support? Contact customer service at 1-(800) 336-4525.
2. How To Wear:
 - 2.1 To optimize performance and get the most secure fit during your workout, cord should be worn in front position.
 - 2.2 For behind the neck use, a cinch is included to improve fit. Adjust the cinch so cord is off your neck but not tight enough that buds pull.
3. Attach Enhancers:
 - 3.1 Install enhancer to earbud by aligning the sound tunnels and gently stretching the enhancer edges as needed.
4. Power/Pair/Charge:
 - 4.1 Power On/Off:
 -  Power On
 -  Power Off
 - 4.2 Pair & Sync:
 -  Pairing Mode
 -  Connected
 - 4.3 Charging Port & Battery Status:
 -  Low Battery
5. 3-Button Command
 - 5.1 Music Control
 - 5.2 Phone Control
 - 5.3 Volume Control

NORSK

1. Select Your Size: Great sound performance is in selecting the correct size enhancer.
 - 1.1 Two sizes of enhancers are included, the smaller size comes installed. Try both sizes to determine your correct fit.
 - 1.2 The correct size will fit securely in the bowl of your ear. If the buds fall out in use, try the larger size.
 - 1.3 Need help sizing or support? Contact customer service at 1-(800) 336-4525.
2. How To Wear:
 - 2.1 To optimize performance and get the most secure fit during your workout, cord should be worn in front position.
 - 2.2 For behind the neck use, a cinch is included to improve fit. Adjust the cinch so cord is off your neck but not tight enough that buds pull.
3. Attach Enhancers:
 - 3.1 Install enhancer to earbud by aligning the sound tunnels and gently stretching the enhancer edges as needed.
4. Power/Pair/Charge:
 - 4.1 Power On/Off:
 -  Power On
 -  Power Off
 - 4.2 Pair & Sync:
 -  Pairing Mode
 -  Connected
 - 4.3 Charging Port & Battery Status:
 -  Low Battery
5. 3-Button Command
 - 5.1 Music Control
 - 5.2 Phone Control
 - 5.3 Volume Control

SVENSKA

1. Select Your Size: Great sound performance is in selecting the correct size enhancer.
 - 1.1 Two sizes of enhancers are included, the smaller size comes installed. Try both sizes to determine your correct fit.
 - 1.2 The correct size will fit securely in the bowl of your ear. If the buds fall out in use, try the larger size.
 - 1.3 Need help sizing or support? Contact customer service at 1-(800) 336-4525.
2. How To Wear:
 - 2.1 To optimize performance and get the most secure fit during your workout, cord should be worn in front position.
 - 2.2 For behind the neck use, a cinch is included to improve fit. Adjust the cinch so cord is off your neck but not tight enough that buds pull.
3. Attach Enhancers:
 - 3.1 Install enhancer to earbud by aligning the sound tunnels and gently stretching the enhancer edges as needed.
4. Power/Pair/Charge:
 - 4.1 Power On/Off:
 -  Power On
 -  Power Off
 - 4.2 Pair & Sync:
 -  Pairing Mode
 -  Connected
 - 4.3 Charging Port & Battery Status:
 -  Low Battery
5. 3-Button Command
 - 5.1 Music Control
 - 5.2 Phone Control
 - 5.3 Volume Control

DANSK

1. Select Your Size: Great sound performance is in selecting the correct size enhancer.
 - 1.1 Two sizes of enhancers are included, the smaller size comes installed. Try both sizes to determine your correct fit.
 - 1.2 The correct size will fit securely in the bowl of your ear. If the buds fall out in use, try the larger size.
 - 1.3 Need help sizing or support? Contact customer service at 1-(800) 336-4525.
2. How To Wear:
 - 2.1 To optimize performance and get the most secure fit during your workout, cord should be worn in front position.
 - 2.2 For behind the neck use, a cinch is included to improve fit. Adjust the cinch so cord is off your neck but not tight enough that buds pull.
3. Attach Enhancers:
 - 3.1 Install enhancer to earbud by aligning the sound tunnels and gently stretching the enhancer edges as needed.
4. Power/Pair/Charge:
 - 4.1 Power On/Off:
 -  Power On
 -  Power Off
 - 4.2 Pair & Sync:
 -  Pairing Mode
 -  Connected
 - 4.3 Charging Port & Battery Status:
 -  Low Battery
5. 3-Button Command
 - 5.1 Music Control
 - 5.2 Phone Control
 - 5.3 Volume Control

繁體中文

1. Select Your Size: Great sound performance is in selecting the correct size enhancer.
 - 1.1 Two sizes of enhancers are included, the smaller size comes installed. Try both sizes to determine your correct fit.
 - 1.2 The correct size will fit securely in the bowl of your ear. If the buds fall out in use, try the larger size.
 - 1.3 Need help sizing or support? Contact customer service at 1-(800) 336-4525.
2. How To Wear:
 - 2.1 To optimize performance and get the most secure fit during your workout, cord should be worn in front position.
 - 2.2 For behind the neck use, a cinch is included to improve fit. Adjust the cinch so cord is off your neck but not tight enough that buds pull.
3. Attach Enhancers:
 - 3.1 Install enhancer to earbud by aligning the sound tunnels and gently stretching the enhancer edges as needed.
4. Power/Pair/Charge:
 - 4.1 Power On/Off:
 -  Power On
 -  Power Off
 - 4.2 Pair & Sync:
 -  Pairing Mode
 -  Connected
 - 4.3 Charging Port & Battery Status:
 -  Low Battery
5. 3-Button Command
 - 5.1 Music Control
 - 5.2 Phone Control
 - 5.3 Volume Control

BAHASA INDONESIA

1. Select Your Size: Great sound performance is in selecting the correct size enhancer.
 - 1.1 Two sizes of enhancers are included, the smaller size comes installed. Try both sizes to determine your correct fit.
 - 1.2 The correct size will fit securely in the bowl of your ear. If the buds fall out in use, try the larger size.
 - 1.3 Need help sizing or support? Contact customer service at 1-(800) 336-4525.
2. How To Wear:
 - 2.1 To optimize performance and get the most secure fit during your workout, cord should be worn in front position.
 - 2.2 For behind the neck use, a cinch is included to improve fit. Adjust the cinch so cord is off your neck but not tight enough that buds pull.
3. Attach Enhancers:
 - 3.1 Install enhancer to earbud by aligning the sound tunnels and gently stretching the enhancer edges as needed.
4. Power/Pair/Charge:
 - 4.1 Power On/Off:
 -  Power On
 -  Power Off
 - 4.2 Pair & Sync:
 -  Pairing Mode
 -  Connected
 - 4.3 Charging Port & Battery Status:
 -  Low Battery
5. 3-Button Command
 - 5.1 Music Control
 - 5.2 Phone Control
 - 5.3 Volume Control

POLSKI

1. Select Your Size: Great sound performance is in selecting the correct size enhancer.
 - 1.1 Two sizes of enhancers are included, the smaller size comes installed. Try both sizes to determine your correct fit.
 - 1.2 The correct size will fit securely in the bowl of your ear. If the buds fall out in use, try the larger size.
 - 1.3 Need help sizing or support? Contact customer service at 1-(800) 336-4525.
2. How To Wear:
 - 2.1 To optimize performance and get the most secure fit during your workout, cord should be worn in front position.
 - 2.2 For behind the neck use, a cinch is included to improve fit. Adjust the cinch so cord is off your neck but not tight enough that buds pull.
3. Attach Enhancers:
 - 3.1 Install enhancer to earbud by aligning the sound tunnels and gently stretching the enhancer edges as needed.
4. Power/Pair/Charge:
 - 4.1 Power On/Off:
 -  Power On
 -  Power Off
 - 4.2 Pair & Sync:
 -  Pairing Mode
 -  Connected
 - 4.3 Charging Port & Battery Status:
 -  Low Battery
5. 3-Button Command
 - 5.1 Music Control
 - 5.2 Phone Control
 - 5.3 Volume Control



Agência Nacional de Telecomunicações

Este equipamento opera em caráter secundário, isto é, não tem direito a proteção contra interferência prejudicial, mesmo de estações do mesmo tipo, e não pode causar interferência a sistemas operando em caráter primário"

Este produto está homologado pela ANATEL, de acordo com os procedimentos regulamentados pela Resolução 242/2000, e atende aos requisitos técnicos aplicados.

Para maiores informações, consulte o site da ANATEL - www.anatel.gov.br



Agência Nacional de Telecomunicações

XXXX-XX-XXXX



CE 0890