






PARTYBOX

ENCORE2 PLUS



WHAT'S IN THE BOX






*The plug type and the quantity of power cords, microphones, and microphone holders vary by regions.

BLUETOOTH PAIRING





Settings Bluetooth

Bluetooth ☒

DEVICES

JBL PB ENCORE 2 PLUS Connected

Now Discoverable

PLAY




x1

x2


x3

LIGHTSHOW




Apply lightshow presets and more with the JBL ONE app.

APP



Download and install the JBL ONE app to get more from the product.




JBL ONE

GET IT ON Google Play

Download on the App Store

MICROPHONE


GUITAR





VOCAL REMOVAL



Vocal removal on/off


Adjust vocal track levels



0% - 25% - 50% - 100%

Adjust vocal track levels

MULTI-SPEAKER CONNECTION




Vocal removal would be disabled during multi-speaker connection.

CHARGING




Do not charge your speaker until it is completely dry and clean.

MICROPHONE HOLDER




PA_JBL_PartyBox Encore 2 Plus_QSG_Global_SOP_V5.indd 1

2025/10/28 11:58:58

