



JBL CINEMA® SB450



4K Ultra-HD 2.1 Soundbar with Wireless Subwoofer

Quick Start Guide




Note: For complete information about using all of your JBL Cinema SB450, download the full Owner's Manual from www.jbl.com.

1 What's in the box




2 Buttons and Controls



2b. Source LED

SOURCE LED BEHAVIOR			
● HDMI 1/2/3	● Aux		
● HDMI TV	● Optical		


2c. Remote control



- 1) Power
- 2) Bluetooth
- 3) JBL Connect
- 4) JBL SoundShift
- 5) Audio Feedback
- 6) Volume +/-
- 7) Mute
- 8) Bass Volume +/-
- 9) HDMI 1 Input
- 10) HDMI 2 Input
- 11) HDMI 3 Input
- 12) HDMI TV Input
- 13) Optical Input
- 14) Aux Input
- 15) Virtual Surround
- 16) Harman Volume

Note: Before using the remote control, remove the plastic tab protecting the battery at the bottom of the remote control.


2d. Soundbar Rear Panel



- 1) USB (Software updates only)
- 2) Power In
- 3) Aux IN
- 4) Optical IN
- 5) HDMI 1
- 6) HDMI 2
- 7) HDMI 3
- 8) HDMI TV
- 9) Subwoofer pairing button
- 10) Wall Mount / Table Mount EQ switch


2e. Subwoofer Rear Panel

Your soundbar and subwoofer are already paired out of the box. If the subwoofer does not automatically connect, press the pairing buttons on soundbar and subwoofer.




- 1) Power
- 2) Wireless Pairing Button
- 3) Crossover
- 4) Power Input AC
- 5) Phase

3 Connecting Devices



4 Bluetooth


Press the Bluetooth button to pair up to 3 wireless devices.
1. Short-press to connect a new device
2. Long-press to disconnect all paired devices.



LED BEHAVIOR	
● Bluetooth icon	Bluetooth Pairing
● Bluetooth icon	Bluetooth Paired


5 JBL SoundShift®

1) SB450 is connected to TV and it is playing TV Sound. Press SoundShift Button, SoundShift Button light turns blue (SoundShift ON).



LED BEHAVIOR	
● SoundShift icon	SoundShift is off
● SoundShift icon	SoundShift is on

2) Press play on a Bluetooth-paired phone, SB450 will auto switch to play phone sound.




You can always turn SoundShift off at any time by pressing the button.


6 JBL Connect

Wirelessly links multiple JBL Connect compatible speakers together.

1) Press connect button on both speakers



2) Speakers connect together and play




LED BEHAVIOR	
● Seeking icon	Seeking JBL Connect Speaker
● Paired icon	Paired with JBL Connect Speaker

NOTE: Only Bluetooth Audio can be shared among the SB450 and other JBL devices.

7 TV Remote Control Learning

Program the soundbar to respond to your own TV remote Control.

1) Enter Learning Mode



2) Learn Power



LED BEHAVIOR	
● Command icon	Command is learned 1s


3) Complete Learning

VOLUME + : Press 'Volume +' on the soundbar and then press 'Volume +' on the TV remote control.
VOLUME - : Press 'Volume -' on the soundbar and then press 'Volume -' on the TV remote control.
MUTE: Press 'Volume +' and 'Volume -' together on the soundbar and then press 'Mute' on the TV remote control.

Press and hold the top panel 'Surround' key again to exit learning mode (the LED will stop blinking).

8 Stereo / Harman Display Surround

Experience virtual surround sound without additional wires or speakers with Harman Display Surround.



To reset the SB450, press and hold Volume+ and Virtual Surround buttons for 5s.

RESTRICTED


DESIGN ADAPTATION / IMAGE / FINAL ART

TR & Job No: TR02323
Job Description: TR02323_JBL_SB450_QSG_A
Version : 8
Date: 2016-06-14
Other: N/A



Developed by
GP01/UK02/UK03/UK04/RT05/ED106/RT07/RT08

**EQUITY COLORS:
REPRESENTATION:**



IMPORTANT NOTE : THE PRINT/PDF IS FOR LAYOUT AND TEXT ILLUSTRATION ONLY. THE COLOURS INDICATED HERE MAY NOT APPEAR SAME IN THE FINAL PROOF. ALTHOUGH EVERY EFFORT HAS BEEN MADE TO CHECK THE CORRECTION OF LAYOUT AND TEXT. IT IS CLIENT RESPONSIBILITY TO VERIFY BEFORE GIVING THE FINAL APPROVAL.