


1	XL1	27 MHZ	49 MHZ
2	C4	33 PF	39 PF
3	C5	51 "	22 "
4	C6	330 "	120 "
5	C9	330 "	220 "
6	C12	68 "	22 "
7	C13	270 "	100 "
8	C14	220 "	100 "
9	L1	1.0 MH	0.22 MH
10	L3	0.02 "	0.47 "
11	L4	0.33 "	0.22 "
12	L5	5.6 "	1.8 "
13	R8	1 K	680 Ω



2101 ZIG ZAG TRANSMITTER CIRCUIT

08.FEB.96