

EXHIBIT 5


User's Manual

User's Manual

AOC

Spectrum Series

Your Work Never Looked Better



9Glr

Owner's Manual

Welcome

Congratulations on your purchase of an AOC monitor. Our monitors are made to the strictest ISO-9001 standards and we stand behind every one of them. The high resolution and flicker free refresh rates will relieve your eyestrain and increase your productivity. You have made a wise investment in this monitor, and we're sure it will deliver quality performance without straining your budget. If you have any questions or problems with your new monitor, visit our online technical support at www.aoclttd.com. Now let's start setting up your new monitor!!

Before operating the monitor please read this manual thoroughly. This manual should be retained for future reference.

FCC Class B Radio Frequency Interference Statement
WARNING: (FOR FCC CERTIFIED MODELS)

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

Notice:

1. The changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
2. Shielded interface cables and A.C. power cord, if any, must be used in order to comply with the emission limits.
3. The manufacturer is not responsible for any radio or TV interference caused by unauthorized modification to this equipment. It is the responsibilities of the user to correct such interference.

As an ENERGY STAR® Partner AOC International has determined that this product meets the ENERGY STAR® guidelines for energy efficiency.

Warning:

To prevent fire or shock hazard, do not expose the monitor to rain or moisture. Dangerously high voltages are present inside the monitor. Do not open the cabinet. Refer servicing to qualified personnel only.

Contents

Packing list	3
Precautions	4
Installation Instructions	5
Swivel Base	5
Power cord	5
Video cable	6
Operating Instructions	7
General Instructions	7
Front panel control	8
How to adjust a setting	8
Adjusting the picture	9-10
Features	11
Green monitor	11
Plug and play	12
Technical Support (FAQ)	13
Appendix A – Specifications	14-15
Appendix B – Factory Preset Timing Table	16
Limited Three-Year Warranty	17-18

PACKING LIST

The product package should include the following items:

1. Monitor
2. Owner's Manual
3. Power Cord
4. Swivel Base
5. Audio Cable/DC Power Cable (For 9GlrSA only)

— Plug & Play Drivers for the AOC Spectrum Series Monitors are available at
AOC's Web Site: www.aocltd.com

PRECAUTIONS

- Do not use the monitor near water, e.g. near a bathtub, washbowl, kitchen sink, laundry tub, swimming pool or in a wet basement.
- Do not place the monitor on an unstable cart, stand, or table. If the monitor falls, it can injure a person and cause serious damage to the appliance. Use only a cart or stand recommended by the manufacturer or sold with the monitor. If you mount the monitor on a wall or shelf, use a mounting kit approved by the manufacturer and follow the kit instructions.
- Slots and openings in the back and bottom of the cabinet are provided for ventilation. To ensure reliable operation of the monitor and to protect it from overheating, be sure these openings are not blocked or covered. Do not place the monitor on a bed, sofa, rug, or similar surface. Do not place the monitor near or over a radiator or heat register. Do not place the monitor in a bookcase or cabinet unless proper ventilation is provided.
- The monitor should be operated only from the type of power source indicated on the label. If you are not sure of the type of power supplied to your home, consult your dealer or local power company.
- The monitor is equipped with a three-pronged grounded plug, a plug with a third (grounding) pin. This plug will fit only into a grounded power outlet as a safety feature. If your outlet does not accommodate the three-wire plug, have an electrician install the correct outlet, or use an adapter to ground the appliance safely. Do not defeat the safety purpose of the grounded plug.
- Unplug the unit during a lightning storm or when it will not be used for long periods of time. This will protect the monitor from damage due to power surges.
- Do not overload power strips and extension cords. Overloading can result in fire or electric shock.
- Never push any object into the slot on the monitor cabinet. It could short circuit parts causing a fire or electric shock. Never spill liquids on the monitor.
- Do not attempt to service the monitor yourself; opening or removing covers can expose you to dangerous voltages and other hazards. Please refer all servicing to qualified service personnel.
- To ensure satisfactory operation, use the monitor only with UL listed computers which have appropriate configured receptacles marked between 100 - 240 VAC, Min. 2.5A.

INSTALLATION INSTRUCTIONS

Swivel Base

To attach the swivel base to the monitor, do the following:

- Carefully turn the monitor on its side or upside down. (see figure 1)
- Locate the cavities at the bottom front of the monitor.
- Insert the pegs on the swivel base into these cavities. Push the swivel base forward until the swivel base locks in place.
- To remove the swivel base, hold the bottom of the swivel base, then push it out.




Figure 1 Installing and Removing the Swivel Base

Power Cord

Power Source:

1. Make sure the power cord is the correct type that required in your area.
2. This monitor has a universal power supply that allows operation in either 100/120V AC or 220/240V AC voltage area (No user adjustment is required.)
3. Connect the power cord into your monitor's power input socket, and then plug the other end into a 3-pin AC power outlet. The power cord may be connected to either a wall power outlet or the power outlet socket on your PC, depending on the type of power cord supplied with your monitor.

Using the Right Power Cord

The accessory power cord for the Northern American region is the wallet plug with NEMA 5-15 style and is UL listed and CSA labeled. The voltage rating for the power cord shall be 125 volts AC.

Supplied with units intended for connection to power outlet of personal computer: Please use a cord set consisting of a minimum No. 18 AWG, type SJT or SVT three conductors flexible cord. One end terminates with a grounding type attachment plug, rated 10A, 250V, CEE-22 male configuration. The other end terminates with a molded-on type connector body, rated 10A, 250V, having standard CEE-22 female configuration.

Video cable

Connecting the Video Cable: The monitor comes with a built-in video cable. Plug the signal cable's 15-pin connector into the computer's video port and tighten the two screws on the cable connector.

Connecting the Power Cord: Plug the power cord into the monitor's AC power socket. Then plug the power cord into a grounded AC outlet or UL-approved power strip or the power output socket on your PC.

Caution: If the AC outlet is not grounded (with three holes), install the proper grounding adapter (not supplied).

Connecting the Audio Cable (9GlrsA only): Plug audio cable between the computer multi-media (or sound) card's audio output and monitor's audio input.

Connecting the DC Power Cable (9GlrsA only): Plug DC power cable between monitor to swivel base for audio power




Figure 2 Connecting Cables

The 9GlrsA is not available till now.

Top Victory does not provide this model before submitted to FCC.

OPERATING INSTRUCTIONS

General Instructions

There is not power switch located at rear side of the monitor. The other control knobs are located at the base of the monitor (See Figure 3). By changing these settings, the picture can be adjusted to your personal preferences.

- The power cord should be connected.
- Connect the video cable from the monitor to the video card.
- To turn the monitor on, press the stand by POWER switch to ON position. The power indicator will light up.
- Your monitor features a unique quick switch system which provides a picture within seconds after the monitor is switched on.




Figure 3 External Control Knob

Notes

- Do not install the monitor in a location near heat sources such as radiators or air ducts, or in a place subject to direct sunlight, or excessive dust or mechanical vibration or shock.
- Save the original shipping carton and packing materials, as they will come in handy if you ever have to ship your monitor.
- For maximum protection, repackage your monitor as it was originally packed at the factory.
- To keep the monitor looking new, periodically clean it with a soft cloth. Stubborn stains may be removed with a cloth lightly dampened with a mild detergent solution. Never use strong solvents such as thinner, benzene, or abrasive cleaners, since these will damage the cabinet. As a safety precaution, always unplug the monitor before cleaning it.

Front Panel Control

- **Standby power key :**

When pressed, the monitor enters the off mode, and the LED turns orange. Press and hold to restore normal status.

- **Shuttle Knob :**

The Shuttle Knob is used to control the monitor functions. Rotate to switch functions or adjust settings. Press to select or execute a function .

- **OSD Key :**

The OSD Key is used to activate the OSD window, or to exit the OSD window and save the settings.

- **Power Indicator :**

Green — Power On mode.

Orange — Stand-by mode, Suspend mode, or
Off mode (Power Saving & Standby Power Off).

Swivel Base Control (9GlrA only) :

- **Audio Power**

ON or OFF Audio Power

- **Power Indicator**

Green — Audio Power ON.

- **Volume**

Adjustable Audio volume.

How to adjust a setting

1. Press the Shuttle Knob or OSD Key to make the OSD window appear. See figure 4.
2. Rotate the Shuttle Knob to select the desired function. See figure 4.
3. Press the Shuttle Knob again to select the function that you want to adjust.
4. Rotate the Shuttle Knob to change the settings of the current function.
5. When the OSD window is active, it shows the input signal timing. The "H" stands for the horizontal frequency and "V" stands for the vertical frequency.
6. To exit and save, either press the OSD Key, select the exit function, or leave the monitor alone for 10 seconds. If you want to adjust any other function, repeat steps 2-4.




Figure 4 The OSD Message

Adjusting the picture

7. The description for functional control icons

- | | | | |
|------|---|--|---|
| 7.1 | CONTRAST | | : |
| | Adjust the picture contrast. | | |
| 7.2 | BRIGHTNESS | | : |
| | Adjust the picture brightness. | | |
| 7.3 | H-CENTER | | : |
| | Adjust the horizontal position of the picture. | | |
| 7.4 | H-SIZE | | : |
| | Adjust the picture's horizontal size. | | |
| 7.5 | V-CENTER | | : |
| | Adjust the vertical position of the picture. | | |
| 7.6 | V-SIZE | | : |
| | Adjust the picture's vertical size. | | |
| 7.7 | ZOOM | | : |
| | Adjust the picture's horizontal and vertical size simultaneously. | | |
| 7.8 | PINCUSHION | | : |
| | Adjust the pincushion and barrel . | | |
| 7.9 | TRAPEZOID | | : |
| | Adjust the picture's trapezoid distortion. | | |
| 7.10 | PIN-BALANCE | | : |
| | Adjust to compensate the pincushion unbalance. | | |

7.11 PARALLELOGRAM



Adjust the picture to be a rectangle.

7.12 ROTATION



Adjust the picture tilt to horizontal position.

7.13 6500°K/9300°K (COLOR TEMPERATURE) :

The color temperature for 6500°K is $x=0.313$, $y=0.329$ and 9300°K is $x=0.281$, $y=0.311$. It presents two different color sets on the screen. You can select 9300°K or 6500°K by pressing the Shuttle Knob.

7.14 USER COLOR (Red / Blue)



If the 9300°K normal white or 6500°K warmer white do not satisfy your desire, properly adjust R B GAIN controls to obtain your optimum whiteness level.

7.15 DEGAUSS



If color impurity occurs when moving or swiveling the monitor, press the Shuttle Knob and degauss to fix the picture condition.

7.16 MOIRE REDUCE



Moire is the result of interference between the phosphor layout and the video signal. In some cases, you may find the moire very noticeable. Press the Shuttle Knob to enter in the moire reduce setting. Please adjust the level to the optimum condition. Note: Too high of a setting will cause the picture to shake.

7.17 RECALL



Press RECALL to restore the monitor to factory settings.

7.18 EXIT



Close OSD window.

FEATURES

Green monitor

- The monitor has a power saving function that conforms to the VESA DPMS standard. This feature will only work if your PC is a green PC. This feature is similar to a screen saver, except that your monitor will turn itself off instead of activating the screen saver.

To activate this feature in Windows® 95:

In Windows® 95, this feature can be activated and customized under the screen saver setting of the display properties.

- Right click on the desktop and choose Properties.
- Click on the tab that says Screen Saver. If your system supports Green PC, there will be a section entitled "Energy Saving Features of Monitor." If there isn't a section like that, then your PC does not support Green Monitor. The monitor will behave just like a normal monitor, so you will have to turn it off manually to save energy.
- In the "Energy Saving Features of Monitor" sections are two boxes, Standby and Shut off. To activate either one, click the box next to each one.
- You can specify the amount of inactive time before your monitor enters standby mode or shuts off.

- The power-saving mode can be indicated by the light-emitting diode (LED) on the front panel:

Mode	Signal				Power	
	Cable	H-Sync	V-Sync	Video	Indicator	Consumption
On*	Attached	Yes	Yes	Active	Green	≤ 150 W
Stand-by	Attached	No	Yes	Blank	Orange	≤ 15 W
Suspend	Attached	Yes	No	Blank	Orange	≤ 15 W
Off	Attached	No	No	Blank	Orange	≤ 5 W

THIS MONITOR WILL APPEAR TO BE NON-FUNCTIONAL IF THERE IS NO VIDEO INPUT SIGNAL. IN ORDER FOR THIS MONITOR TO OPERATE PROPERLY, THERE MUST BE A VIDEO INPUT SIGNAL.

This monitor meets the Power Management standards as set by the Video Electronics Standards Association (VESA) and/or the United States Environmental Protection Agency (EPA) and The Swedish Confederation Employees (NUTEK). This feature is designed to conserve electrical energy by reducing power consumption when there is no video input signal present. When there is no video input signal this monitor, following a time-out period, will automatically switch to an OFF mode. This reduces the monitor's internal power supply consumption. After the video input signal is restored, full power is restored and the display is automatically redrawn. The appearance is similar to a "Screen Saver" feature except the display is completely off. The display is restored by pressing a key on the keyboard, or clicking the mouse.

Plug and play

Plug & Play DDC1/2B Feature

This monitor is equipped with VESA DDC1/2B capabilities according to the VESA DDC STANDARD. It allows the monitor to inform the host system of its identity and, depending on the level of DDC used, communicate additional information about its display capabilities. The communication channel is defined in two levels, DDC1 and DDC2B.

The DDC1 is a unidirectional data channel from the display to the host that continuously transmits EDID information. The DDC2B is a bidirectional data channel based on the I²C protocol. The host can request EDID information over the DDC2B channel.

Video Cable Pin Assignments:

1. Red	5. Ground	9. NC	13. H-sync
2. Green	6. R-Ground	10. Ground	14. V- sync / * VCLK
3. Blue	7. G-Ground	11. Monitor Ground	15. DDC-Serial Clock
4. Ground	8. B-Ground	12. DDC-Serial Data	* FOR DDC

TECHNICAL SUPPORT (FAQ)

Problem & Question	Possible Solution
Power LED is not on	*Check if the Power Switch is in the ON position *Power Cord should be connected
No Plug & Play	*Check if the PC system is Plug & Play compatible *Check if the Video Card is Plug & Play compatible *Check if the D-15 plug pin of Video Cable is bent *Make sure the AOC Monitor Drivers are installed (AOC Monitor Drivers are available at: www.aocltd.com)
No picture	*Computer Power Switch should be in the ON position *Computer Video Card should be snugly seated in its slot *The Signal Cable should be completely connected to the computer *Check the color of the Power LED indicator. If it is orange, then the monitor and the PC system are in power-saving mode. You need press your keyboard or move the mouse to reactivate the system.
Picture is fuzzy	*Adjust the Contrast and Brightness Controls.
Picture bounces or a wave pattern is present in the picture	* Move electrical devices that may cause electrical interference.
Monitor is stuck in "Power Saving Mode"	*Make sure monitor's video cable is properly connected to the computer. *Inspect monitor's video cable and make sure none of the pins are bent. *Make sure computer is operational by hitting the CAPS LOCK key on the keyboard while observing the CAPS LOCK LED. The LED should either turn ON or OFF after hitting the CAPS LOCK key.
Missing one of the primary colors (RED, GREEN, or BLUE)	*Inspect the monitor's video cable and make sure that none of the pins are bent.

APPENDIX A - SPECIFICATIONS

CRT	48.3cm(19"), 100° deflection, 29mm neck, 0.26mm dot pitch non-glare screen.
Viewable Image Size	45.7cm (18.0"), diagonal
Display Color	Unlimited colors
Input Signal	Analog input All timing that meets scanning frequencies
• Video • Sync.	• Analog R, G, B 0.7Vpp positive/75 ohm • Horizontal sync. : Positive/Negative • Vertical sync. : Positive/Negative
Synchronization	
• Horizontal • Vertical	30KHz to 95KHz automatically 50Hz to 150Hz automatically
Max. Resolution	1600 × 1200
Video bandwidth	135MHz
Factory Preset Timings :	15
User mode Timings :	9
Misconvergence	
• Center • Corner	0.3mm Max. 0.4mm Max.
Power Source	Switching mode power supply AC 100-240V, 50Hz/60Hz full range
Operating Humidity	0°C to 40°C ambient 10% to 85% relative, non-condensing
Weight	19.5Kgs(Net), 23.3Kgs(Gross) for 9Glrs 20.3Kgs(Net), 24.1Kgs(Gross) for 9GlrsA
Dimensions	
• Carton • Monitor	590(W) × 537(H) × 574(D)mm 460(W) × 466(H) × 420(D)mm for 9Glrs 460(W) × 503(H) × 420(D)mm for 9GlrsA
Signal Cable	15 pin mini D-Sub
External Controls:	
Switch	• Shuttle Knob • Standby Power Switch • OSD Key

Functions (OSD)	• Contrast • Brightness • H-Center • H-Size • V-Center • V-Size • Zoom • Pincushion • Trapezoid • Pin Balance • Parallelogram • Rotation • 6500°K • User color • 9300°K • Degauss • Moire Reduce • Recall • Exit
Plug & Play	DDC1/2B
Power management	EPA , VESA DPMS
Power consumption	150 Watts Max.
Preset display area	346mm × 260 mm
Speaker (9GlrsA only)	
• Rate power	2W
• Impedance	8Ω
Audio (9GlrsA only)	
• Audio output	1 W × 2
• Frequency response	100Hz ~ 15KHz @ ± 3dB
• Distortion	< 3%
• Input sensitivity	0.9Vpp ~ 1.1Vpp
Regulations	UL, CSA, FDA, FCC, TÜV / GS, CE MPRII TCO'92 or TCO'95

The 9GlrsA is not available till now.

Top Victory does not provide this model before submitted to FCC.

APPENDIX B – FACTORY PRESET TIMING TABLE

STANDARD	RESOLUTION	HORIZONTAL FREQUENCY	VERTICAL FREQUENCY
VGA	720 × 400	31.46KHz	70Hz
VGA	640 × 480	31.46KHz	60Hz
VESA/75	640 × 480	37.5KHz	75Hz
VESA/85	640 × 480	43KHz	85Hz
VESA/75	800 × 600	46.9KHz	75Hz
VESA/60	1024 × 768	48.4KHz	60Hz
VESA/85	800 × 600	53.6KHz	85Hz
VESA/75	1024 × 768	60KHz	75Hz
VESA/60	1280 × 1024	64KHz	60Hz
VESA/85	1024 × 768	68.8KHz	85Hz
VESA/60	1600× 1200	75KHz	60Hz
VESA/75	1280 × 1024	79.9KHz	75Hz
VESA/85	1280 × 960	85.938KHz	85Hz
VESA/85	1280× 1024	91.14KHz	85Hz
VESA/75	1600× 1200	93.75KHz	75Hz

LIMITED THREE-YEAR WARRANTY

for AOC Color Monitors

Including those Sold within the European Countries as Specified

AOC International warrants this product to be free from defects in material and workmanship for a period of three (3) years after the original date of consumer purchase. During this period, AOC International will, at its option, either repair the defective product with new or rebuilt parts, or replace it with a new or rebuilt product at no charge except as *stated below. The parts or product that are replaced become the property of AOC International (USA) Ltd.

In the USA to obtain service under this limited warranty, call AOC International for the name of the Authorized Service Center in your area. Deliver the product freight pre-paid, along with the dated proof of purchase, to the AOC Authorized Service Center. If you cannot deliver the product in person:

- Pack it in its original shipping container (or equivalent)
- Put the RMA number on the address label
- Put the RMA number on the shipping carton
- Insure it (or assume the risk of loss / damage during shipment)
- Pay all shipping charges

— AOC International is not responsible for damage to inbound product that was not properly packaged.

AOC International will pay the return shipment charges within one of the countries specified within this warranty statement. AOC International is not responsible for any costs associated with the transportation of product across international borders. This includes the international borders of the countries within this warranty statements.

In the United States contact your Dealer or AOC International Customer Service, RMA Department at the toll free number (800) 775-1262.

In Canada, Europe (this warranty is valid in the member countries of the European Community). Contact your Dealer, Reseller, Distributor or the organization where you obtained your monitor in case of problems during the warranty period in order to receive factory level approved service. In Europe all repairs will be done at AOC Authorized Service Centers similar to the ones in the USA.

* This limited warranty does not cover any losses or damages that occur as a result of:

- Shipping or improper installation or maintenance
- Misuse
- ● Neglect
- Any cause other than ordinary commercial or industrial application

- Adjustment by non-authorized source
- Repair, modification, or installation of options or parts by anyone other than an AOC Authorized Service Center
- Improper environment
- Excessive or inadequate heating or air conditioning or electrical power failures, surges, or other irregularities

This three-year limited warranty does not cover any of the product's firmware or hardware that you or any third party have modified or altered; you bear the sole responsibility and liability for any such modification or alteration.

ALL EXPRESS AND IMPLIED WARRANTIES FOR THIS PRODUCT (INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE) ARE LIMITED IN DURATION TO A PERIOD OF THREE (3) YEARS FOR PARTS AND LABOR FROM THE ORIGINAL DATE OF CONSUMER PURCHASE. NO WARRANTIES (EITHER EXPRESSED OR IMPLIED) APPLY AFTER THIS PERIOD. IN THE UNITED STATES OF AMERICA, SOME STATES DO NOT ALLOW LIMITATIONS ON HOW LONG AN IMPLIED WARRANTY LASTS, SO THE ABOVE LIMITATIONS MAY NOT APPLY TO YOU.

AOC INTERNATIONAL'S OBLIGATIONS AND YOUR REMEDIES HEREUNDER ARE SOLELY AND EXCLUSIVELY AS STATED HERE. AOC INTERNATIONAL'S LIABILITY, WHETHER BASED ON CONTRACT, TORT, WARRANTY, STRICT LIABILITY, OR OTHER THEORY, SHALL NOT EXCEED THE PRICE OF THE INDIVIDUAL UNIT WHOSE DEFECT OR DAMAGE IS THE BASIS OF THE CLAIM. IN NO EVENT SHALL AOC INTERNATIONAL BE LIABLE FOR ANY LOSS OF PROFITS, LOSS OF USE OR FACILITIES OR EQUIPMENT OR OTHER INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGE. IN THE UNITED STATES OF AMERICA, SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES. SO THE ABOVE LIMITATION MAY NOT APPLY TO YOU. ALTHOUGH THIS LIMITED WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY HAVE OTHER RIGHTS WHICH MAY VARY FROM STATE TO STATE.

In the United States of America, this limited warranty is only valid for Products purchased in the Continental United States, Alaska, and Hawaii.

Outside the United States of America, this limited warranty is only valid for Products purchased in Canada and the member countries of the European Union.