

1 GENERAL DESCRIPTION

1.1 Description

This Programming Manual is included with the Programming Software files that are located on the RESRP16 Software CD. The RESRP16 Windows based programming software described in this user manual applies to the RPV516A, RPV516B, and RPU416A model transceivers.

1.2 Minimum System Requirements

- ◆ IBM™ or Compatible PC
- ◆ 486/90 MHz PC or higher
- ◆ 10 MB Hard Drive space
- ◆ 32 MB Ram
- ◆ Operating System: Windows 95, Windows 98, Windows NT4.0, or Windows 2000
- ◆ Video Resolution: 800 x 600

1.3 Technical Assistance

If you need technical assistance, contact a RELM Communications service technician:

By Letter:	RELM Wireless Corporation ATTN: Customer Service 7100 Technology Drive West Melbourne, FL 32904
By Phone:	(800) 422-6281
By FAX	(321) 953-7986
By Email:	service@RELM.com