



nyne

Aqua

- CS

Přenosného reproduktoru Bluetooth
- ET

Kaasaskantav Bluetooth kõlar
- GE

für einen portablen Bluetooth-Lautsprecher
- HU

Rövidített használati útmutató
- LV

Pārnēsājams Bluetooth skaļrunis
- LT

Garsiakalbio vartotojo vadovas
- PL

Przenośnego głośnika Bluetooth
- RO

Difuzor portabil Bluetooth
- SK

Prenosného reproduktoraBluetooth
- CS

Stručná příručka uživatele
- ET

Lühike kasutusjuhend
- GE

verkürztes Benutzerhandbuch
- HU

Hordozható Bluetooth hangszóró
- LV

Saīsināta Lietotāja Rokasgrāmata
- LT

Sutrumpintas nešiojamo bluetooth
- PL



Skrócony Przewodnik Użytkownika
- RO

Ghid de referință rapidă
- SK

Stručná príručka uživatela


nyne.com

CE 2200



Charge the speaker until the red power indicator turns off.


Tip: If the power indicator flashes red quickly, it indicates that the battery is low and needs to be recharged.



Press and hold until the Bluetooth indicator flashes blue.

For first-time use, the Bluetooth indicator flashes blue quickly, indicating that the speaker is in pairing mode.

Tip: When you power on the speaker again after Bluetooth setup, the speaker will search for the paired device and the Bluetooth indicator will flash slowly. If no paired device is found, it will flash quickly and the speaker will enter pairing mode.




- 1 Make sure that the speaker is in pairing mode.
- 2 Enable Bluetooth on your device to be paired with the speaker.
- 3 Select 'NYNE AQUA' from the available devices (enter the password '0000' if necessary) to start pairing and connection with the speaker.
- 4 After successful connection, the Bluetooth indicator turns solid blue and the speaker beeps.

Tip: This speaker supports automatic connection with a previously paired device after power-off and power-on again.

You can press and hold for more than 2 seconds to enter manual pairing mode. In this way, you can pair the speaker with a new Bluetooth device.

You can press and hold both +/- for more than 5 seconds to clear all paired Bluetooth devices. This speaker is compatible with the voice assistant on your smart device.






QU-G-Aqua-06-23-2014-V1.0

All registered and unregistered trademarks are
property of their respective owners.
Nyne Multimedia Inc.
All rights reserved.

nyne



Play music on your device paired
and connected with the speaker.

 **Note:** This speaker supports automatic
connection with a previously paired device
after power-off and power-on again.

During music play:

- Press **+/-** to adjust volume.
- Press and hold **+/-** to skip to
the previous or next song.
- Press **⏸** to pause or resume music play.
- Press **EQ** to select your favorite preset
sound effect: FLAT, ROCK, POP or JAZZ.
- Press and hold **EQ** for more than 3
seconds to return to FLAT at any time.


- ☞ The Bluetooth indicator flashes
blue once when you select a
sound effect other than FLAT.
- ☞ The Bluetooth indicator flashes blue
twice when you select FLAT.

When you make a call or there is
an incoming call, you can use the
speaker as a speaker phone.

- When there is an incoming call, you
can press **📞** to receive the call or
press **📞** twice to reject the call.
- During a call, you can press **📞** to end the call.
- In BT mode, you can press **📞** twice to access
the voice assistant on your smart device. To
exit the voice assistant, press **📞** twice again.

 **Tips:** Music play is paused during a call and
resumed automatically when the call ends.

You can press and hold **📞** to disconnect
the current Bluetooth connection.
If no source is detected, the **EQ**
button does not function.



FCC STATEMENT

1.This device complies with Part 15 of the FCC Rules.Operation is subject to the following two conditions:
(1)This device may not cause harmful interference, and (2)This device must accept any interference
received, including interference that may cause undesired operation. 2.Changes or modifications not expressly
approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC Radiation Exposure Statement:

The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition without RF striction.
NOTE: This equipment has been tested and found to comply with the limits for a Class B
digital, pursuant to Part 15 or the FCC Rules. These limits are designed to provide
reasonable protection against harmful interference in a residential installation. This
equipment generates, uses and can radiate radio frequency energy and, if not installed and
used in accordance with the instructions, may cause harmful interference to radio
communications. However, there is no guarantee that interference will not occur in a
particular installation. If the equipment does cause harmful interference to radio or
television reception, which can be determined by turning the equipment off and on, the user
is encouraged to try to correct the interference by one or more of the following measures:
--- Reorient or relocate the receiving antenna.
--- Connect the equipment into an outlet on a circuit different
from that to which the receiver is connected.
--- Consult the dealer or an experienced radio/ TV technician for help.

- 1 Connect an auxiliary audio
device to the speaker through the
supplied 3.5mm audio cable.
- 2 Play and control music on the audio
device, and use **+/-** on the speaker
to adjust volume if necessary.

 **Tips:** In AUX IN mode, you can press **🔇**
to mute sound output from the speaker.
When the 3.5mm audio cable is plugged
in, the speaker switches to AUX IN mode
automatically. When it is unplugged, the
speaker switches back to Bluetooth mode.

The **EQ** button also functions in AUX IN mode.
The voice assistant function does
not work in AUX IN mode.

In case of abnormality, you can hold
the **RESET** button to reset the speaker.