

Manuals and Software

- **Instruction Manual (this booklet)**

Be sure to read before use.

- **Advanced User Guide**

For detailed camera instructions, refer to the Advanced User Guide at the following website.

<https://cam.start.canon/C023/>



- **Software, Instruction Manuals for Lenses and Software**

View or download from the following website.

<https://cam.start.canon/>



Preliminary Notes and Legal Information

- Read this manual carefully to ensure correct use. Keep it handy for future reference.
- Information subject to change without notice, as are product specifications and appearance. Illustrations and screenshots may differ slightly from actual products.
- The above items notwithstanding, Canon cannot be held liable for any loss arising from the use of this product.
- Take and review some test shots initially to make sure the images were recorded correctly. Please note that Canon Inc., its subsidiaries and affiliates, and its distributors are not liable for any consequential damages arising from any malfunction of a camera or accessory, including memory cards, that result in the failure of an image to be recorded or to be recorded in a way that is machine readable.
- When shooting backlit subjects, keep the sun sufficiently away from the angle of view. Always keep intense light sources such as the sun, lasers, and other intense artificial light sources out of the image area and not near it. Concentrated intense light may cause smoke or damage the image sensor or other internal components.
- Attach the lens cap to prevent direct sunlight and other light from entering the lens when you are not shooting.
- Battery Pack LP-E6P is included with the product.
- For trademark information, refer to the Advanced User Guide.

Safety Instructions

Be sure to read these instructions in order to operate the product safely. Follow these instructions to prevent injury or harm to the operator of the product or others.



WARNING: Denotes the risk of serious injury or death.

- Keep the product out of the reach of young children.
- Keep batteries out of the reach of children.

A strap wrapped around a person's neck may result in strangulation.

The parts or provided items of cameras or accessories are dangerous if swallowed. If swallowed, seek immediate medical assistance.

The battery is dangerous if swallowed. If swallowed, seek immediate medical assistance.

○ PRODUCT CONTAINS BUTTON/COIN CELL BATTERY

Button/coin cell batteries are hazardous and must be kept out of reach of children at all times, whether new or used.

These batteries can cause severe or fatal injuries in 2 hours or less if swallowed or placed inside any part of the body.

If it is suspected a button/coin cell battery has been swallowed or placed inside any part of the body, seek medical attention immediately.

- Use only power sources specified in this instruction manual for use with the product.
- Do not disassemble or modify the product.
- Do not expose the product to strong shocks or vibration.
- Do not touch any exposed internal parts.
- Stop using the product in any case of unusual circumstances such as the presence of smoke or a strange smell.
- Do not use organic solvents such as alcohol, benzine or paint thinner to clean the product.
- Do not get the product wet. Do not insert foreign objects or liquids into the product.
- Do not use the product where flammable gases may be present. This may cause electric shock, explosion or fire.
- Do not leave a lens or a camera/camcorder with a lens attached, exposed without the lens cap attached.

The lens may concentrate the light and cause fire.

- Do not touch the product connected to a power outlet during lightning storms. This may cause electric shock.
- Observe the following instructions when using commercially available batteries or provided battery packs.
 - Use batteries/battery packs only with their specified product.
 - Do not heat batteries/battery packs or expose them to fire.
 - Do not charge batteries/battery packs using non-authorized battery chargers.
 - Do not expose the terminals to dirt or let them come into contact with metallic pins or other metal objects.
 - Do not use leaking batteries/battery packs.
 - When disposing of batteries/battery packs, insulate the terminals with tape or other means. This may cause electric shock, explosion or fire.

Safety Instructions

If a battery/battery pack leaks and the material contacts your skin or clothing, flush the exposed area thoroughly with running water. In case of eye contact, flush thoroughly with copious amounts of clean running water and seek immediate medical assistance.

- Observe the following instructions when using a battery charger or AC adapter.
 - Periodically remove any dust buildup from the power plug and power outlet using a dry cloth.
 - Do not plug in or unplug the product with wet hands.
 - Do not use the product if the power plug is not fully inserted into the power outlet.
 - Do not expose the power plug and terminals to dirt or let them come into contact with metallic pins or other metal objects.
 - Do not touch the battery charger or AC adapter connected to a power outlet during lightning storms.
- Do not place heavy objects on the power cord. Do not damage, break or modify the power cord.
- Do not wrap the product in cloth or other materials when in use or shortly after use when the product is still warm in temperature.
- Do not unplug the product by pulling the power cord.
- Do not leave the product connected to a power source for long periods of time.
- Do not charge batteries/battery packs at temperatures outside the range of 5–40 °C (41–104 °F).

This may cause electric shock, explosion or fire.

- Do not allow the product to maintain contact with the same area of skin for extended periods of time during use.

This may result in low-temperature contact burns, including skin redness and blistering, even if the product does not feel hot. The use of a tripod or similar equipment is recommended when using the product in hot places and for people with circulation problems or less sensitive skin.

- Follow any indications to turn off the product in places where its use is forbidden. Not doing so may cause other equipment to malfunction due to the effect of electromagnetic waves and even result in accidents.
- Do not leave batteries near pets.

Pets biting a battery could cause leakage, overheating, or explosion, resulting in product damage or fire.



CAUTION: Follow the cautions below. Otherwise physical injury or property damage may result.

- Do not fire the flash near the eyes. It may hurt the eyes.
- Do not look at the screen or through the viewfinder (on products with a viewfinder) for extended periods.

This may induce symptoms similar to motion sickness. In such a case, stop using the product immediately and rest for a while before resuming use.


- Flash emits high temperatures when fired. Keep fingers, any other part of your body, and objects away from the flash unit while taking pictures. This may cause burns or malfunction of the flash.
- Do not leave the product in places exposed to extremely high or low temperatures. The product may become extremely hot/cold and cause burns or injury when touched.

Safety Instructions

- Strap is intended for use on the body only. Hanging the strap with any product attached on a hook or other object may damage the product. Also, do not shake the product or expose the product to strong impacts.
- Do not apply strong pressure on the lens or allow an object to hit it. This may cause injury or damage to the product.
- Only mount the product on a tripod that is sufficiently sturdy.
- Do not carry the product when it is mounted on a tripod. This may cause injury or may result in an accident.
- Do not touch any parts inside the product. This may cause injury.
- If any abnormal skin reaction or irritation occurs during or following the use of this product, refrain from further use and get medical advice/attention.



- After movie recording or repeated continuous shooting over an extended period, do not touch the screen storage compartment (A), which may be hot. This may cause burns.



(A)

- The camera and memory cards are more likely to become hotter when [📷: Auto pwr off temp.] is set to [High].
 - We recommend using a tripod or the like to avoid handheld shooting, which may cause problems such as low-temperature contact burns.
 - Do not touch CFexpress cards immediately after shooting. Cards may be hot, which may cause burns. Wait until the card has cooled down before removing it.

Areas of Use and Restrictions for EOS R6 V

To comply with local radio wave regulations in various areas around the world, Canon offers region-specific versions of the transmitter (DS126932, DS126933, DS126934, DS126935 and DS126936).

Please do not use your regional version of the transmitter in regions it was not designed for.

For information on areas where your regional version of the transmitter can be used, refer to the Canon Web site.

Wireless LAN Restrictions

When wireless networking is used, channels in gray in the following table cannot be used. These restrictions are established by local regulations, which must be upheld.

Although the other channels can be used, some restrictions apply to certain channels, as noted.

		(1)	(2)				
			W52	W53	W56	W58	
DS126932	(3)	(5)	1-11	36-48	52-64	100-140	149-165
		(6)	1-11	36-48	52-64	100-140	149-165
	(4)	(5)	1-11	36-48	52-64	100-140	149-165
		(6)	1-11	36-48	52-64	100-140	149-165
DS126933	(3)	(5)	1-11	36-48	52-64	100-140	149-165
		(6)	1-11	36-48	52-64	100-140	149-165
	(4)	(5)	1-11	36-48	52-64	100-140	149-165
		(6)	1-11	36-48	52-64	100-140	149-165
DS126934	(3)	(5)	1-11	36-48	52-64	100-140	149-165
		(6)	1-11	36-48	52-64	100-140	149-165
	(4)	(5)	1-11	36-48	52-64	100-140	149-165
		(6)	1-11	36-48	52-64	100-140	149-165
DS126935	(3)	(5)	1-11	36-48	52-64	100-140*	149-165
		(6)	1-11	36-48	52-64	100-140	149-165
	(4)	(5)	1-11	36-48	52-64	100-140*	149-165
		(6)	1-11	36-48	52-64	100-140	149-165
DS126936	(3)	(5)	1-11	36-48	52-64	100-140	149-165
		(6)	1-11	36-48	52-64	100-140	149-165
	(4)	(5)	1-11	36-48	52-64	100-140	149-165
		(6)	1-11	36-48	52-64	100-140	149-165

(1):Wireless LAN Connection Method

(2):Channel

(3):Indoors

(4):Outdoors

(5):Infrastructure

(6):Camera Access Point Mode

* In Russia, use on channels 100-128 is prohibited.

These models incorporate wireless module ES204:

DS126932, DS126933, DS126934, DS126935 and

DS126936.

Supplementary Information

CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE.
DISPOSE OF USED BATTERIES ACCORDING TO LOCAL REGULATIONS.

**IMPORTANT SAFETY INSTRUCTIONS-
SAVE THESE INSTRUCTIONS.
DANGER-TO REDUCE THE RISK OF
FIRE OR ELECTRIC SHOCK,
CAREFULLY FOLLOW THESE
INSTRUCTIONS.**

If the shape of the plug does not fit the power outlet, use an attachment
plug adaptor of the proper configuration for the power outlet.



USA and Canada only:

The Lithium ion/polymer battery that powers the product is
recyclable.

Please call 1-800-8-BATTERY for information on how to
recycle this battery.

Graphical symbols placed on the equipment



Class II equipment



Direct current



Alternating current

FCC/ISED(IC) Notice

Model:DS126933

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s).

Operation is subject to the following two conditions:

- (1) This device may not cause interference.
- (2) This device must accept any interference, including interference that may cause undesired operation of the device.

This transmitter must not be co-located or operated in conjunction with any other antenna or transmitter.

The available scientific evidence does not show that any health problems are associated with using low power wireless devices. There is no proof, however, that these low power wireless devices are absolutely safe. Low power Wireless devices emit low levels of radio frequency energy (RF) in the microwave range while being used. Whereas high levels of RF can produce health effects (by heating tissue), exposure of low-level RF that does not produce heating effects causes no known adverse health effects. Many studies of low-level RF exposures have not found any biological effects. Some studies have suggested that some biological effects might occur, but such findings have not been confirmed by additional research. This model has been tested and found to comply with FCC/ISED radiation exposure limits set forth for an uncontrolled environment and meets the FCC radio frequency (RF) Exposure Guidelines and RSS-102 of the ISED radio frequency (RF) Exposure rules.

5.15-5.35 GHz band is restricted to indoor operations only.

Frequency Tolerance:20 ppm

Compliance with FCC requirement 15.407(c)

Data transmission is always initiated by software, which is the passed down through the MAC, through the digital and analog baseband, and finally to the RF chip. Several special packets are initiated by the MAC. These are the only ways the digital baseband portion will turn on the RF transmitter, which it then turns off at the end of the packet. Therefore, the transmitter will be on only while one of the aforementioned packets is being transmitted. In other words, this device automatically discontinues transmission in case of either absence of information to transmit or operational failure.

Use in combination with genuine Canon accessories is recommended.

Use of USB cables designated as genuine Canon accessories is recommended.

Use a commercially available HDMI cable (connector on side of camera is type A). Use of cables that are no longer than 2m is recommended.

For CA, USA only

Included lithium battery contains Perchlorate Material - special handling may apply.

See www.dtsc.ca.gov/hazardouswaste/perchlorate for details.

FCC Notice

(This Product, Model DS126933 systems)

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions;

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for Class B digital devices, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The cable with the ferrite core provided with the digital camera must be used with this equipment in order to comply with Class B limits in Subpart B of Part 15 of the FCC rules.

Do not make any changes or modifications to the equipment unless otherwise specified in the manual. If such changes or modifications should be made, you could be required to stop operation of the equipment.

Canon U.S.A., Inc.
One Canon Park, Melville, New York 11747, U.S.A.
Tel No. 1-800-OK-CANON (1-800-652-2666)

Canadian Radio Interference Regulations

CAN ICES(B)/NMB(B)

Complies with
IMDA Standards
DB00671

Some logos for technical standards the camera has met can be viewed on the screen by choosing MENU ►  tab ► **[Certification Logo Display]**.

-India only-

This product is not to be disposed of with your household waste. This product should be handed over to a designated collection point. For more information regarding return and recycling of WEEE products, please visit <https://in.canon/en/consumer/web/e-waste> or write to us at cipl.ewaste@canon.co.in

Also, this product including its components, consumables, parts and spares complies with the "E-Waste (Management) Rules, 2022" and prohibits use of lead, mercury, hexavalent chromium, polybrominated biphenyls or polybrominated diphenyl ethers in concentrations exceeding 0.1 % by weight and 0.01 % by weight for Cadmium, except for the exemptions set in Schedule II of the Rules.



⚠ WARNING


- **INGESTION HAZARD:** This product contains a button cell or coin battery.
- **DEATH** or serious injury can occur if ingested.
- A swallowed button cell or coin battery can cause **Internal Chemical Burns** in as little as **2 hours**.
- **KEEP** new and used batteries **OUT OF REACH of CHILDREN**.
- **Seek immediate medical attention** if a battery is suspected to be swallowed or inserted inside any part of the body.



- Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate.
- Even used batteries may cause severe injury or death.
- Call a local poison control center for treatment information.
- The button cell or coin battery type/model is MS614SE or its equivalent.
- The battery nominal voltage is 3V.
- Non-rechargeable batteries are not to be recharged.
- Do not force discharge, recharge, disassemble, heat above (manufacturer's specified temperature rating) or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.
- This product contains a non-replaceable button cell or coin battery.
- This icon  indicates that the product contains a button cell or coin battery.

The General Certificate of Conformity required under the Consumer Product Safety Act and related regulations is furnished and accessible and can be obtained at product_safety@cusa.canon.com

Only for European Union and EEA (Norway, Iceland and Liechtenstein)



These symbols indicate that this product is not to be disposed of with your household waste, according to the WEEE Directive (2012/19/EU), the Battery Regulation ((EU) 2023/1542) and/or national legislations implementing those Directive and Regulation. If a chemical symbol is printed beneath the symbol shown above, in accordance with the Battery Regulation, this indicates that a heavy metal (Pb = Lead) is present in this

battery at a concentration above an applicable threshold specified in the Battery Regulation.

This product should be handed over to a designated collection point, e.g., on an authorized one-for-one basis when you buy a new similar product or to an authorized collection site for recycling waste electrical and electronic equipment (EEE) and batteries. Improper handling of this type of waste could have a possible impact on the environment and human health due to potentially hazardous substances that are generally associated with EEE. Your cooperation in the correct disposal of this product will contribute to the effective usage of natural resources. For more information about the recycling of this product, please contact your local city office, waste authority, approved scheme or your household waste disposal service or visit www.canon-europe.com/sustainability/approach/.

Observe the following precautions when using, transporting or storing batteries or battery packs, including built-in batteries.

Avoid extremely high or low temperatures. Leaving a battery in extremely hot places may cause leaks of flammable liquids or gases and present a risk of fire or explosion.

Avoid conditions of low pressure at high altitudes. Leaving a battery in extremely low pressure conditions may cause leaks of flammable liquids or gases and present a risk of fire or explosion.

Do not throw batteries or battery packs into an open fire, stove or furnace and do not crush, puncture or disassemble batteries. This may cause explosion.

Battery Charger Model: LC-E6E/LC-E6

Equipment markings are located on the back of the charger.

The power delivered by the charger must be between min 7.5 Watts required by the radio equipment, and max 7.5 Watts in order to achieve the maximum charging speed.

The model number is DS126934 / DS126935 (including WLAN module and Bluetooth module model ES204). To identify your model, check the label on the bottom of the camera or behind the tilt-up screen for a number beginning with DS.

Countries and Regions Permitting Wireless Function Use

- Use of wireless function is restricted in some countries and regions, and illegal use may be punishable under national or local regulations. To avoid violating wireless regulations, visit the Canon website to check where use is allowed. Note that Canon cannot be held liable for any problems arising from wireless function use in other countries and regions.

Doing any of the following may incur legal penalties:

- Altering or modifying the product
- Removing the certification labels from the product

Do not use the wireless function of this product near medical equipment or other electronic equipment.

Use of the wireless function near medical equipment or other electronic equipment may affect operation of those devices.

Hereby, Canon Inc. declares that this equipment is in compliance with Directive 2014/53/EU.

The full text of the EU declaration of conformity is available at the following internet address: <http://www.canon-europe.com/ce-documentation>

DS126934

Wi-Fi Frequency range: 2400-2483.5 MHz Wi-

Fi Maximum output power: 13.0 dBm

DS126935

Wi-Fi Frequency range: 2400-2483.5 MHz, 5150-5350 MHz, 5470-5725 MHz, 5725-5850 MHz

Wi-Fi Maximum output power: 13.0 dBm, 14.9 dBm, 14.9 dBm, 13.96 dBm

DS126934 / DS126935

Bluetooth Frequency range: 2400-2483.5 MHz

Bluetooth Maximum output power: 8.98 dBm

5.15-5.35 GHz band is restricted to indoor operations only.

CANON EUROPA N.V. Bovenkerkerweg 59, 1185 XB Amstelveen, The Netherlands

CANON INC. 30-2, Shimomaruko 3-chome, Ohta-ku, Tokyo 146-8501, Japan

For UK

Hereby, Canon Inc. declares that this equipment is in compliance with the relevant statutory requirements.

The full text of the declaration of conformity is available at the following internet address: <https://www.canon-europe.com/ce-documentation/>

Wi-Fi Frequency range: 2400-2483.5 MHz, 5150-5350 MHz, 5470-5725 MHz, 5725-5850 MHz

Wi-Fi Maximum output power: 13.0 dBm, 14.9 dBm, 14.9 dBm, 13.96 dBm

Bluetooth Frequency range: 2400-2483.5 MHz

Bluetooth Maximum output power: 8.98 dBm

5.15-5.35 GHz band is restricted to indoor operations only.

Equipment must not form part of a fixed outdoors installation.

CANON (UK) Limited

4 Roundwood Avenue, Stockley Park, Uxbridge, UB11 1AF, U.K.


UK PSTI Statement of Compliance (for the UK only)

In accordance with the terms of the Product Security and Telecommunications Infrastructure Act 2022 (the "PSTI Act"), Canon Inc. of 30-2 Shimomaruko, 3-Chome Ohta-ku, Tokyo 146-8501, Japan, as the manufacturer, declares that the EOS R6 V complies with the applicable security requirements set out in Schedule 1 of the PSTI.

The defined support period, when Canon Inc. first supplied the product, is 31 December 2029. This support period may be subject to extension based on the product lifecycle. The full Statement of Compliance, including the latest support period information, is available online at www.canon.co.uk/pssti or by scanning the QR code.



Only for the United Kingdom



These symbols indicate that this product is not to be disposed of with your household waste, according to the UK Waste Electrical and Electronic Equipment Regulations and the UK Batteries and Accumulators Regulations.

If a chemical symbol is printed beneath the symbol shown above, in accordance with the UK Batteries and Accumulators

Regulations, this indicates that a heavy metal (Hg = Mercury, Cd = Cadmium, Pb = Lead) is present in this battery or accumulator at a concentration above an applicable threshold specified in the UK Batteries and Accumulators Regulations.

This product should be handed over to a designated collection point, e.g., on an authorized one-for-one basis when you buy a new similar product or to an authorized collection site for recycling waste electrical and electronic equipment (EEE) and batteries and accumulators. Improper handling of this type of waste could have a possible impact on the environment and human health due to potentially hazardous substances that are generally associated with EEE. Your cooperation in the correct disposal of this product will contribute to the effective usage of natural resources.

For more information about the recycling of this product, please contact your local city office, waste authority, approved scheme or your household waste disposal service or visit www.canon-europe.com/sustainability/approach/.

- The warranty of the product(s) is effective only in the country written on your warranty certificate.

 CAUTION

Do not ingest battery, Chemical Burn Hazard.

This product contains a coin or button cell battery. If the coin or button cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death.

Keep new and used batteries away from children.

If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

