

## EUT Internal Photos

Figure 3  
Internal View (Removed Battery Cover)




Figure 4  
Internal View (Removed Cover)




Figure 5  
Internal View (IT300A-8 Board)




Figure 6  
Internal View




Figure 7  
Internal View (IT300A-12 Board, Front View)




Figure 8  
Internal View (IT300A-12 Board, Back View)




Figure 9  
Internal View (IT300A-10 Board, Front View)




Figure 10  
Internal View (IT300A-10 Board, Back View)




Figure 11  
Internal View (Removed IT300A-13 Board)




Figure 12  
Internal View (IT300A-13 Board, Front View)




Figure 13  
Internal View (IT300A-13 Board, Back View)




Figure 14  
Internal View




Figure 15  
Internal View (IT300A-1 Board, Back View)




Figure 16  
Internal View (IT300A-1 Board and RF Board)




Figure 17  
Internal View (IT300A-1 Board, Front View)




Figure 18  
Internal View (RF Board, Removed Shielded Cover)




Figure 19  
Internal View (RF Board, Front View)




Figure 20  
Internal View (RF Board, Back View)




Figure 21  
Internal View (Display, Front View)




Figure 22  
Internal View (Display, Back View)




Figure 23  
Internal View (IT300A-11 Board, Front View)




Figure 24  
Internal View (IT300A-11 Board, Back View)




Figure 25  
Internal View (IT300A-5 and IT300A-6 Board)

