

## EUT Internal Photos

Figure 5  
Internal View (Removed Battery Cover)



Figure 6  
Internal View (Removed Battery Case)



Figure 7  
Internal View (Removed RF ANT)



Figure 8  
Internal View (Removed Covers)




Figure 9  
Internal View (TC11A-A Board)






Figure 10  
Internal View (TC11A-9 Board, Front View)



*Figure 11*  
*Internal View (TC11A-9 Board, Back View)*



*Figure 12*  
*Internal View*



*Figure 13*  
*Internal View (Display, Front View)*



*Figure 14*  
*Internal View (Display, Back View)*




Figure 15  
Internal View (RF ANT)




Figure 16  
Internal View




Figure 17  
Internal View (Control Board)





Figure 18  
Internal View (TC11A-5 Board, Front View)



*Figure 19*  
*Internal View (TC11A-5 Board, Back View)*



*Figure 20*  
*Internal View (TC11A-6 Board, Front View)*




Figure 21  
Internal View (TC11A-6 Board, Back View)



Figure 22  
Internal View (TC11A-2 Board, Front View)




Figure 23  
Internal View (TC11A-2 Board, Back View)




Figure 24  
Internal View (TC11A-1 Board, Front View)




Figure 25  
Internal View (TC11A-1 Board, Back View)




Figure 26  
Internal View (TC11A-1 Board, Removed RF Board)




Figure 27  
Internal View (RF Board, Front View)




Figure 28  
Internal View (RF Board, Back View)

