



GE Interlogix

IR Sensor

Installation Instructions

www.GE-Interlogix.com

Document Number: 466-20xx Rev. A
June 2003
PRELIMINARY

Preliminary 6/27/03

Product Summary

Part No. 60-XXX

An Infra-Red Sensor.

Installation

- **To mount the IR Sensor:**
 1. Attach magnetic strip to sensor plastic.
 2. Attach sensor to metal surface.

Programming

- **To learn the IR Sensor into the panel:**
 1. Open the cover.
 2. Hold the tamper switch down until the LED flashes.
 3. Replace the Cover.

Notices

This device complies with FCC Rules Part 15. Operation is subject to the following two conditions.

This device may not cause harmful interference.

This device must accept any interference that may be received. Including interference that may cause undesired operation.

Changes or modifications not expressly approved by GE Interlogix can void the user's authority to operate the equipment.

FCC ID: B4Z-587-IR



GE Interlogix

© 2003 GE Interlogix. Something is a registered trademark of GE Interlogix. Something else is a trademark of GE Interlogix. All other trademarks are properties of their owners.

All rights reserved.

2266 Second Street North
North Saint Paul MN 55109
Technical Support: 800-777-2624