



14. SETUP PHOTOS

RADIATED RF MEASUREMENT SETUP







ANTENNA PORT CONDUCTED RF MEASUREMENT SETUP



FREQUENCY STATIBILITY MEASUREMENT SETUP



DIGITAL DEVICE RADIATED EMISSIONS SETUP





POWERLINE CONDUCTED EMISSIONS MEASUREMENT SETUP

LINE CONDUCTED FRONT PHOTO



LINE CONDUCTED BACK PHOTO



15. APPENDIX

EXHIBIT 1: User Manual

EXHIBIT 2: EUT External Photos

EXHIBIT 3: EUT Internal Photos

EXHIBIT 4: Schematic

EXHIBIT 5: Block Diagram

EXHIBIT 6: Operational Description

EXHIBIT 7: Report of Measurements

EXHIBIT 8: Setup photo

EXHIBIT 9: Labeling