



Quick Start Guide v2

HyperX Cloud Flight 2

Wireless Gaming Headset

Overview



- A. Mic mute / monitoring button
- B. Status LED
- C. Power button
- D. USB-C charge port
- E. Microphone port / internal microphone
- F. Multifunction button
- G. Volume wheel
- H. Wireless mode switch
- I. [Removable earcup plates](#)
- J. [Customizable RGB lighting](#)
- K. Detachable microphone
- L. Microphone mute LED
- M. [USB wireless dongle](#)
- N. Dongle status LED
- O. Pairing pin hole
- P. USB-C to USB-A adapter
- Q. [USB charge cable](#)

Charging


It is recommended to fully charge your headset before first use.

[Use the following line drawing:

- Using USB charge cable
 - Connect one end to headset USB-C charge port of laptop
 - Connect USB-C to USB-A adapter to PC

]

[Reference Image



]

Charge Status	Status [LED]
Fully Charged	Solid Green
61% — 99%	Breathing Green
21% — 60%	Breathing Yellow
< 20%	Breathing Red


Usage

Adapter Mode (2.4GHz)

1. Slide the headset wireless mode switch to .
2. Connect the USB wireless dongle to your device.
3. Power **ON** the headset.

[Use the following line drawing:]

[Reference Image



OMEN Gaming Laptop

[Use the following line drawings:

- ¾ view of headset with microphone attached
- Laptop
 - Use OMEN laptop line art if available [Reuse Cloud III S Wireless Assets]

]

[Reference images:



]

1. Power on the gaming laptop.
2. Power on the headset. The headset will automatically connect to the gaming laptop. *


NOTE: After the headset is paired, double press the power button to switch between OMEN gaming laptop connection or the USB wireless dongle connection.

*Supported only on compatible OMEN Gaming Laptops.

**Laptop shown for illustration purposes only.


Bluetooth Mode

1. Slide the wireless mode switch to . The headset will enter Bluetooth pairing on the first setup.
2. Go to your device Bluetooth settings, search, and connect to “**HyperX Cloud Flight 2 Wireless**”.



Bluetooth Pairing

1. Slide the wireless mode switch to .
2. Press and hold both the power button and the multifunction button for 2s. Pairing mode is active when the LED blinks blue and the voice prompt says, "Bluetooth pairing".
3. Go to your device's Bluetooth settings and connect to "**HyperX Cloud Flight 2 Wireless**".




Setup

[\[Reuse Cloud III S Wireless Assets\]](#)

Windows 11

1. Right-click on the sound icon in the system tray and select Sound Settings.



2. Set the output device to Headphones [**HyperX Cloud Flight 2 Wireless**].
3. Set the input device to Microphone [**HyperX Cloud Flight 2 Wireless**].

PlayStation 5

Go to the home page and select **Settings > Sound**.

Microphone

- Input Device: USB Headset “**HyperX Cloud Flight 2 Wireless**”.

Audio Output

- Output Device: USB Headset “**HyperX Cloud Flight 2 Wireless**”.
- Output to Headphones: **All Audio**.

Headset Controls

Status LED

Status	Adapter Mode	Bluetooth Mode
Pairing	Fast blinking white	Fast blinking blue
Searching	Blinking white	Blinking blue
Connected	Solid-fade white for 5s	Solid-fade blue for 5s

Power button

- Power on/off – Hold button for 2 seconds to power headset on/off.
- Battery level status – Press button to check the battery level.

The status LED will automatically turn off to conserve battery life.

Battery Level	Headset Status LED
61% to 100%	Solid-fade green
21% to 60%	Solid-fade yellow
10% to 20%	Solid-fade red
< 10%	Short-blink red

- Connection switch – When paired with OMEN gaming laptops, double press button to switch between OMEN gaming laptop connection and USB wireless dongle connection.

Mic mute / mic monitoring button

- Mic mute toggle – Press button to turn the mic mute on/off.
- Mic monitoring toggle – Hold button for 2 seconds to toggle mic monitoring on/off.

Multifunction button

Single Press	Double Press	Triple Press	Long Press (2s) [Translate in time]
Play / Pause Answer Call	Skip Track End Call Reject Call	Previous Track	Activate Voice Assistant

Note: Button functionality can vary between devices and apps.

Volume wheel

- [Scroll wheel to adjust volume level.](#)

RGB lighting

- Press both power and multifunction [buttons](#) to toggle RGB LEDs on/off. *

* [Software required to customize RGB colors and lighting effects.](#)

HyperX NGENUITY Software

Go to hyperx.com/ngenuity to download the NGENUITY software. NGENUITY software features include:

- [RGB lighting customization](#)
- DTS Headphone:X*
- Adjustable auto shut-off behavior
- Battery level indicator

*PC only

[\[NGENUITY logo\]](#) [\[DTS logo\]](#)

[\[Reference images:](#)



[\]](#)

Questions or Setup Issues?

Contact the HyperX support team or see the user manual at hyperx.com/support

WARNING: Permanent hearing damage can occur if a headset is used at high volumes for extended periods of time.

Battery/TX Power Info

Battery Information	Battery Type: 3.7V, 1000mAh Li-Po Battery, 3.7Wh Rechargeable battery can be replaced by user
----------------------------	--

Radio Technology	Frequency Bands: 2.4GHz, Bluetooth
Frequency and TX Power Information	Maximum Transmit Power EIRP (dBm): Headset: ≤ 10dBm USB wireless dongle: ≤ 10dBm

Battery Replacement

1. Power **OFF** the headset.
2. Carefully pull the right ear cushion from the headset.
3. Unscrew the 4x Philips screws to separate the driver cover from the right earcup.
4. Gently separate the cover from the earcup to avoid any damage.
5. Locate and remove the battery secured with a connector.
6. Place new battery matching correct pin orientation.
7. Close the driver cover and earcup. Reverse steps 3 and 2. Make sure to push cushion into the slot all around the earcup.
8. Power **ON** the headset and test for functionality.

CAUTION

Risk of fire or explosion if the battery is replaced by an incorrect type

ATTENTION

Risque d'incendie ou d'explosion si la batterie est remplacée par un type incorrect

Wireless Headset/無線耳機/无线耳机

Regulatory Model/型號/型号: HXHS244

USB Wireless Dongle /USB 無線訊號轉換器/ 无线讯号转换器

Regulatory Model/型號/型号: HXWD245