



REMOVE CAMERA FROM WATERPROOF CASE

1. To open the backdoor of the case, hold the camera so that you are looking at the screen and press the backdoor release button on the right while pulling the latch towards you. Remove the camera from the case.



REMOVE BATTERY

2. Make sure to completely charge the battery before initial use. To charge the battery, use the USB cord provided in the package and plug into a power source while

connected to the camera with the battery installed. The red LED light will illuminate while charging, and the battery symbol on the screen will show a full charge.

***Note: The camera will automatically record for approximately 70 minutes on a fully charged battery.

STORAGE

4. Find the MicroSDHC slot on the side of the camera. Insert your MicroSDHC card into the slot, and press until it clicks. Make sure the card is inserted correctly to avoid damage to the card or card reader.

***Note: MicroSDHC card sold separately. MicroSDHC Class 10/UHS-I or higher required, up to 32GB.


POWER ON

5. Power on the camera by pressing and holding the button located on the front of the camera marked "mode".

BUCKLE MOUNTING SYSTEM

6. Most of the ROX included accessories utilize the buckle mounting system.


6a. Attach adhesive mount to a clean surface at room temperature.




FIN-STYLE MOUNTING SYSTEM

7. The ROX camera also utilizes the fin-style mounting system. Just unscrew the mounting bracket from the camera and attach it to the mount. Insert the case fins with the mount and push the camera into place. Then use the mounting screw to secure the camera.

When in the waterproof case, the ROX camera can be submerged in up to 30M (99ft) of water. Please note that the camera is NOT waterproof when out of the waterproof case.



7b. Align the pins on the camera with the slots on the mount. Push camera into slot.



RECORD

8. Toggle between video, photo, and playback modes by pressing the Power/Mode button on the top of the camera. Press the button marked "On" on the top of the camera. Press the button again to stop the recording.

WASPCam ROX APP

9. The WASPCam ROX App lets you view and share video without the need to connect to a computer. Download WASPCam ROX app from the App Store or Google Play Store. Turn Wi-Fi on the camera by holding the up button on the side of the camera. Connect the camera to the App and connect to the camera with the Wi-Fi SSID and Password shown on the camera screen.

***Make sure Wi-Fi is turned on the camera before you are connecting to the camera.

FCC Statement

Changes or modifications not expressly approved by the user may void the user's warranty. This equipment has been tested and found to comply with the requirements of Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference to other licensed operations.

(1) This device must not cause interference, and (2) This device must accept any interference, including that from unauthorized stations, that may cause undesired operation of the device.

FCC Statement

Changes or modifications not expressly approved by the user may void the user's warranty. This equipment has been tested and found to comply with the requirements of Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference to other licensed operations.

(1) This device must not cause interference, and (2) This device must accept any interference, including that from unauthorized stations, that may cause undesired operation of the device.

(1) This device may not cause harmful interference, and (2) This device must accept any interference, including that from unauthorized stations, that may cause undesired operation.

IC Statement

This equipment complies with Industry Canada's license-exempt RSSI. Operation is subject to the following two conditions: (1) L'appareil ne doit pas produire de brouillage et (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

(1) This device may not cause harmful interference, and (2) This device must accept any interference, including that from unauthorized stations, that may cause undesired operation of the device.

IC Statement

This equipment complies with Industry Canada's license-exempt RSSI. Operation is subject to the following two conditions: (1) L'appareil ne doit pas produire de brouillage et (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.