















HIGH CHANNEL 9 BANDEDGE ANT 3




OUT-OF-BAND HIGH CHANNEL 9 ANT 3




HIGH CHANNEL 10 BANDEDGE ANT 3




OUT-OF-BAND HIGH CHANNEL 10 ANT 3




HIGH CHANNEL 11 BANDEDGE ANT 3




OUT-OF-BAND HIGH CHANNEL 11 ANT 3




HIGH CHANNEL 12 BANDEDGE ANT 3



OUT-OF-BAND HIGH CHANNEL 12 ANT 3




HIGH CHANNEL 13 BANDEDGE ANT 3









OUT-OF-BAND HIGH CHANNEL 13 ANT 3

8.5.2. 802.11n HT20 SISO MODE


1TX ANT 4 MODE









HIGH CHANNEL 10 BANDEDGE




OUT-OF-BAND HIGH CHANNEL 10



HIGH CHANNEL 11 BANDEDGE




OUT-OF-BAND HIGH CHANNEL 11




HIGH CHANNEL 12 BANDEDGE




OUT-OF-BAND HIGH CHANNEL 12




1TX ANT 3 MODE







HIGH CHANNEL 10 BANDEDGE




OUT-OF-BAND HIGH CHANNEL 10




HIGH CHANNEL 11 BANDEDGE





OUT-OF-BAND HIGH CHANNEL 11



HIGH CHANNEL 12 BANDEDGE




OUT-OF-BAND HIGH CHANNEL 12




8.5.3. 802.11n HT20 CDD MODE 2TX


2TX ANT 4 + ANT 3 MODE




LOW CHANNEL 1 BANDEDGE ANT 4




OUT-OF-BAND LOW CHANNEL 1 ANT 4




LOW CHANNEL 2 BANDEDGE ANT 4




OUT-OF-BAND LOW CHANNEL 2 ANT 4




LOW CHANNEL 3 BANDEDGE ANT 4




OUT-OF-BAND LOW CHANNEL 3 ANT 4




LOW CHANNEL 4 BANDEDGE ANT 4




OUT-OF-BAND LOW CHANNEL 4 ANT 4




IN-BAND REFERENCE LEVEL ANT 4




OUT-OF-BAND MID CHANNEL ANT 4




HIGH CHANNEL 8 BANDEDGE ANT 4




OUT-OF-BAND HIGH CHANNEL 8 ANT 4




HIGH CHANNEL 9 BANDEDGE ANT 4




OUT-OF-BAND HIGH CHANNEL 9 ANT 4




HIGH CHANNEL 10 BANDEDGE ANT 4



OUT-OF-BAND HIGH CHANNEL 10 ANT 4



HIGH CHANNEL 11 BANDEDGE ANT 4



OUT-OF-BAND HIGH CHANNEL 11 ANT 4

