

Dr. Bott's ExtendAIR

for Apple Airport BaseStation

Installation instructions (Draft 1)

1. Remove AC power from Airport Base Station.
2. Connect ExtendAIR to the available antenna port on Airport Base Station
3. Reconnect AC power to Airport Base Station.

Apple's Airport Base Station automatically configures itself to use ExtendAIR external antennas.

(Insert wallmount instructions here.)

Power connector
removal image

ExtendAIR connection
image

Power connector
reconnect image



Approved for use only with FCC ID: BCGA1026 (United States)
Approved for use only with IC:579C-A1026 (Canada)

ExtendAIR Omni Model number: DBWAMONI
ExtendAIR Direct Model number: DBWADIRE

