


12. SETUP PHOTOS

12.1. ANTENNA PORT CONDUCTED RF MEASUREMENT SETUP




12.2. RADIATED RF MEASUREMENT SETUP (BELOW 1 GHz)

RADIATED FRONT PHOTO (BELOW 1 GHz)



RADIATED BACK PHOTO (BELOW 1 GHz)




12.3. RADIATED RF MEASUREMENT SETUP FOR PORTABLE CONFIGURATION

X-AXIS FRONT PHOTO



X-AXIS BACK PHOTO



Y-AXIS FRONT PHOTO



Y-AXIS BACK PHOTO



Z-AXIS FRONT PHOTO



Z-AXIS BACK PHOTO



12.4. POWERLINE CONDUCTED EMISSIONS MEASUREMENT SETUP

LINE CONDUCTED FRONT PHOTO





LINE CONDUCTED BACK PHOTO



12.5. DYNAMIC FREQUENCY SELECTION MEASUREMENT SETUP

12.5.1. STANDARD CLIENT MODE




DFS FRONT PHOTO (CLIENT MODE SETUP)




12.5.2. CLIENT TO CLIENT MODE


DFS FRONT PHOTO (EUT)



DFS SIDE PHOTO (EUT)



DFS FRONT PHOTO (CLIENT-TO-CLIENT COMMUNICATIONS
MODE SETUP)



END OF REPORT