

A2461, A2462

Front: Multi-Touch Display, FaceTime Camera



A2461, A2462

Back Housing: Rear Camera, Microphone, Smart Connector



A2461, A2462

Left Side: Microphone




A2461, A2462

Top Side: Microphone, Speakers, Sleep/Wake Button



A2461, A2462

Right Side: Volume up/down buttons, Wireless
charger for Pencil, SIM Tray



A2461, A2462

Bottom Side: USB-C Adaptor, Speakers

