

A2686

Top




A2686

Bottom



A2686

Front Side – Status Light Indicator




A2686

Rear Side - Power Button,
Headphone jack, HDMI port,
Two USB-A ports, A/C Inlet,
Gigabit Ethernet port,
Two USB-C ports



A2686

Left Side



A2686

Right Side

