


A2837, A3006

Front: Multi-Touch Display,
Front Camera



A2837, A3006

Back Housing: Rear Camera,
Microphone, Smart Connector




A2837, A3006

Top Side: Power/Sleep/Wake Button, Microphone,
Speakers



A2837, A3006
Left Side: Microphone



A2837, A3006

Right Side: Wireless Charger for Pencil, Volume Up/
Down Buttons



A2837, A3006
Bottom Side: USB-C Connector, Speakers

