




(Front)



(Side)

Configuration of EUT and connecting equipments.


Stand-by state mode(FAX mode)

(AC Powerline Conducted Emission)

Picture 1




(Front)




(Side)

Configuration of EUT and connecting equipments.
PC reception operation mode(PC mode)
(AC Powerline Conducted Emission)

Picture 2



(Front)




(Rear)

Configuration of EUT and connecting equipments.


Copy operation mode (FAX mode)

(Radiated Emission)

Picture 3



(Front)



(Rear)

Configuration of EUT and connecting equipments.
PC print operation mode(PC mode)
(Radiated Emission)

Picture 4