

Test Setup photographs

EUT Position: X-axis




Test Setup photographs

EUT Position: Y-axis



Test Setup photographs

EUT Position: Z-axis



Test Setup photographs

EUT Position: X-axis



Test Setup photographs

EUT Position: Y-axis



Test Setup photographs

EUT Position: Z-axis



Test Setup photographs

