

FLATRON

LCD 565LM

User's Guide
Manuel d'utilisation
Guía del Usuario
Manual do proprietário

Please read this manual carefully before operating your set.
Retain it for future reference.
Record model number and serial number of the set.
See the label attached on the back cover and quote this
information to your dealer when you require service.

Color Monitor



LG Electronics Inc.

<http://www.lge.com>

Mexico only:

LG Electronics México S.A. de C.V.
Sor Juana Inés de la Cruz No. 555 Col. San Lorenzo
Tlalreparta, Edo. de México C.P. 54033
Tel. 321 19 00 fax 565 75 49
Lada sin costo 01 800 50 481 00



As an ENERGY STAR Partner
LG Electronics U. S. A., Inc.
has determined that this product
meets the ENERGY STAR
guidelines for energy efficiency.

P/NO : 3828TUL

Printed in Korea



Contents

Introduction	A1	Introducción	E1
Connecting the Monitor	A2	Conectando del Monitor	E2
Location and Function of Controls	A4	Ubicación y Funcion de los Controles	E4
Control Panel Function	A5	Función del Panel de Control	E5
On Screen Display (OSD) Control Adjustment	A6	Ajuste del Control de Exhibición en Pantalla (OSD)	E6
On Screen Display(OSD) Selection		Ajuste del OSD y Selección de Elementos	E7
and Adjustment	A7	Modos de Memoria de Video	E9
Video Memory Modes	A9	Sugerencias para Localizar las Fallas	E10
Troubleshooting	A10	Especificaciones	E11
Specifications	A11	Introdução	F1
Einleitung	B1	Conectando o Monitor	F2
Anschließen	B2	Posição dos Controles e Descrição	F4
Ort und Funktion der Bedienungselemente	B4	Funções do Painel de Controle	F5
Bedienungselemente der Bildkontrolle	B5	Ajuste On Screen Display(OSD)	F6
On Screen Display (OSD) Anpassung	B6	Ajustes OSD e Itens de Seleção	F7
OSD Einstellung und Auswahlssymbole	B7	Modos de Memória de Vídeo	F9
Videospeichermodi	B9	Resolvendo Problemas	F10
Störungen	B10	Especificações	F11
Produktbeschreibung	B11	Inteiding	N1
Introduction	C1	De Monitor Aansluiten	N2
Branchement du Moniteur	C2	De plaatsing en de werking van de knoppen	N4
Nomenclature et Fonctions	C4	Het bedieningspaneel	N5
Fonctions du Paneau de Commande	C5	Bediening via het beeldscherm OSD	
Réglage des Commandes Affichage Écran	C6	(On Screen Display)	N6
Options de sélection et de Réglage		Kiezen en instellen via het OSD-systeem	N7
OSD (affichage écran)	C7	Modi voor videogeheugen	N9
Mise en Mémoire de Modes Vidéo	C9	Problemen oplossen	N10
Quelques Conseils en Cas D'incident	C10	Specificaties	N11
Spécifications D'entree	C11		
Introduzione	D1		
Collegamento del Monitor	D2		
Posizione e Funzione dei Conando di Controllo	D4		
Funzione del Pannello di Controllo	D5		
Controllo Regolazione On Screen Display (OSD)	D6		
Elementi di Selezione e Regolazione dell'OSD	D7		
Modalità di Memoria Video	D9		
In Caso di Problemi	D10		
Specifiche	D11		

Introduction

The FLATRON LCD 575LM Flat Panel Monitor has an active matrix TFT (Thin-Film Transistor) LCD (Liquid Crystal Display). This monitor is designed for use in small working areas or for those who need more working space on the desk.

ENGLISH

Features


- The FLATRON LCD 575LM is a 15 inch (15 inches viewable) intelligent microprocessor based monitor.
- Digitally controlled auto-scanning is done with the micro-processor for horizontal scan frequencies between 31 and 61kHz, and vertical scan frequencies between 56 - 75Hz.
- This monitor provides audio function. Thanks to built in audio function in the speaker, you can easily separate speakers from the monitor and place them where you want.
- We accomplished to adapt the advanced design and technology to the monitor. Soft touch buttons on the front panel are simple and allow you to conveniently adjust a variety of image controls. The absolute flat screen and screen surface treatment eliminate distracting glares.
- It supports resolutions up to 1024x768, and has a wide viewing angle of ± 50 degrees horizontal and $+30, -40$ degrees vertical.
- Plug and play capability if supported by your system.
- This monitor has DDC 2B function.*
- Compliant with the following regulated specifications :*
 - EPA ENERGY STAR
 - Swedish TCO'99

**For detailed information, please refer to the Reference Guide provided.*

Connecting the Monitor

To set up the monitor, ensure that the power is turned off to the monitor, computer system, and other attached devices, then follow these steps:

- 1 Power off both the monitor and computer.
- 2 Slightly press and pull the latch on Stand cover.
- 3 Connect one end of the monitor signal cable to the input connector on the rear panel of the monitor.
- 4 Connect the other end to the 15-pin connector on the rear panel of the computer and tighten the screws. Be sure the signal cable aligns with the 15-pin connector.
- 5 Connect the other end of the monitor signal cable to the rear panel of Macintosh computer through a Macintosh adapter and then tighten screws.
- 6 Connect the plug from the AC adapter into the base of the monitor.
- 7 Connect one end of the AC power cord to the AC adapter and the other end to a properly grounded AC outlet that is easily accessible and close to the monitor.
- 8 Power on the computer, then the monitor.
- 9 If you see the "CHECKED" message, check the signal cable and connectors.
- 10 After using the system, power OFF the monitor, then the computer.




CHECK If you see the "CHECKED" message, check to make sure your system is set to one of the factory preset modes (see page A9), or is set to a resolution and refresh rate within the specification limits of this monitor.


Connecting the Monitor

Connection the Audio


1. Connect the speaker as described in below picture.
2. Connect the one end of Audio DC power cable, which is attached on the speaker to AUDIO DC OUT connector ❶ and the other end to DC 24V connector ❷ on the back of the speaker. Then connect the audio cable port which is directly connected to the speaker to AUDIO L-OUT port ❸.
3. Connect the audio cable from the Speaker's AUDIO IN port ❹ to the audio output port of your computer's sound card.



4. After connecting both cables, fix them with cable fixed holder (extra cable fixed holders are shipped with the speaker).




5. Turn on the speaker with power button and adjust volume to proper level.




Location and Function of Controls

Front View





Rear View



Control Panel Function

Front Panel Controls



Control	Function
 OSD Button  	Use this button to enter or exit the on screen display. Use these buttons to choose or adjust items in the on screen display. <Shortcut Keys> Brightness and Contrast can be adjusted directly without entering the On Screen Display (OSD) system. Touch the ◀▶/Δ▽ buttons to adjust the settings and then the OSD button to save all changes. The Brightness and Contrast functions are also available in the On Screen Display (OSD) menu.
 AUTO/SET Button 	Use this button to enter a selection in the on screen display. * AUTO adjustment function Touch the AUTO/SET button before using OSD menu. This button is for the automatic adjustment of the screen position, clock and phase. Note: Some signal from some graphics boards may not function properly. If the results are unsatisfactory, adjust your monitor's Position, Clock and Phase manually.
 Power Button	Use this button to turn the monitor on or off.
 Power Indicator	The power indicator light is shown in the power button. This indicator lights up green when the monitor operates normally. If the monitor is in DPM (Energy Saving) mode (stand-by/ suspend/power off), this indicator color changes to amber.


On Screen Display (OSD) Control Adjustment

Making adjustments to the image size, position and operating parameters of the monitor are quick and easy with the On Screen Display Control system. A quick example is given below to familiarize you with the use of the controls. Following section is an outline of the available adjustments and selections you can make using the OSD.

NOTE

- Allow the monitor to stabilize for at least 30 minutes before making image adjustment.

To make adjustments in the On Screen Display, follow these steps:






- 1 Press the , then the main menu of the OSD appears.
- 2 To access a control, use the  or   or  . When the icon you want becomes highlighted, press the .
- 3 Use the ///  to adjust the item to the desired level.
- 4 Accept the changes by pressing the .
- 5 Exit the OSD by Pressing the .



On Screen Display(OSD) Selection and Adjustment

You were introduced to the procedure of selection and adjusting an item using the OSD system.

Listed below are the icons, icon names, and icon descriptions of the items that are shown on the Menu.

OSD Adjust	Description
	 Brightness Used to adjust the brightness of the screen.  Contrast Adjust the display to the contrast desired.
	PRESET 9300K/ 6500K To appear the displays color temperature. RED • 9300K:Slightly bluish white. • 6500K:Slightly reddish white. To set your own color levels. GREEN To set your own color levels. BLUE To set your own color levels.
	 Vertical Position To move image up and down.  Horizontal Position To move picture image left and right.

On Screen Display(OSD) Selection and Adjustment

OSD Adjust	Description
	CLOCK To minimize any vertical bars or stripes visible on the screen background. The horizontal screen size will also change. PHASE To adjust the focus of the display. This item allows you to remove any horizontal noise and clear or sharpen the image of characters.
	LANGUAGE To choose the language in which the control names are displayed. OSD POSITION To adjust position of the OSD window on the screen. BEEP To select beep ON or OFF. ELAPSED TIME To display the use time of monitor

Video Memory Modes

The monitor has 30 memory locations for display modes, 14 of which are factory preset to popular video modes.

Display Modes (Resolution)

Display Modes (Resolution)	Horizontal Freq.(kHz)	Vertical Freq.(Hz)
1 VGA 640 x 350	31.47	70
2 VGA 720 x 400	31.47	70
3 VGA 640 x 480	31.47	60
4 MAC 640 x 480	35.00	67
5 VESA 640 x 480	37.86	73
6 VESA 640 x 480	37.50	75
7 VESA 800 x 600	35.16	56
8 VESA 800 x 600	37.88	60
9 VESA 800 x 600	48.08	72
10 VESA 800 x 600	46.88	75
11 MAC 832 x 624	49.72	75
12 VESA 1024 x 768	48.36	60
13 VESA 1024 x 768	56.48	70
14 VESA 1024 x 768	60.02	75

Note : This LCD monitor has been pre-adjusted to the video mode of VESA 1024x768 @75Hz.



User Modes

- Modes 15-30 are empty and can accept new video data. If the monitor detects a new video mode that has not been present before or is not one of the preset modes, it stores the new mode automatically in one of the empty modes starting with mode 15.

If you use up the 16 blank modes and still have more new video modes, the monitor replaces the information in the user modes starting with mode 15.

Troubleshooting

Check the following before calling for service.

- 
- Push the  Button.
 - If the results are unsatisfactory, adjust the image position using the H position and V position icon in the on screen display.
- 
- Push the  Button.
 - If the results are unsatisfactory, decrease the vertical bars or stripes using the  icon in the on screen display.
- 
- Push the  Button.
 - If the results are unsatisfactory, decrease the horizontal bars using the  icon in the on screen display.
- 
- The signal cable is not connected, or is loose. Check and secure the connection.
- 
- The frequency of the signal from the video card is outside the operating range of the monitor.
- 
- 
- ☐ Use the graphics board's utility software to change the frequency setting (Refer to the manual for graphics board).
- ☐ You can change the setup to the supported resolution using the  (Press the F8 key during booting the system).
- 
- The monitor is in its display power management mode.
 - There is no active signal coming from the PC.
 - The signal cable is not fastened securely.
 - Check the computer power and graphics adapter configuration.
- 
- Computer video signal is not VESA DPMS standard. Either the PC or the video controller card is not using the VESA DPMS power management function.

NOTE

- If the power indicator(LED) light is blinking amber, may result in abnormal condition of the monitor.
- Then press a power ON/OFF button on the front panel control and call your service technician for more information.

Specifications

Display	□□□□	15inch (38.1cm) Flat Panel Active matrix-TFT LCD
		Anti-Glare coating
	□□□□ □□□□□□□□	15inch (38.1cm)
	□□□□□□□□□□	0.297 x 0.297mm
Sync Input	□□□□□□□□□□	16 million color
	□□□□□□□□□□□□	31kHz - 61kHz (Automatic)
	□□□□□□□□□□□□	56Hz - 75Hz (Automatic)
	□□□□□□□□	Separate, TTL, Positive/Negative
Video Input	□□□□□□□□□□	15 pin D-Sub connector
	□□□□□□□□□□	304 x 228mm / 12.0 x 9.0inch
	□□□□□□□□□□	Separate, RGB Analog, 0.714Vp-p/75ohm, Positive
	□□□□□□□□□□□□	VESA 1024 x 768 @ 75Hz
Audio	□□ □□□□□□□□□□	1W(R+L)
	□□□□□□□□□□□□□□	0.7Vrms
	□□□□□□□□□□□□□□	4Ω
Power Consumption	□□□□ □□□□ □□□□	≤ 36W
	□□□□□□□□□□□□□□	≤ 3W
	□□□□ □□□□ □□	≤ 3W
Dimensions	□□□□	39.4 cm / 15.5 inches (without speaker)
		52.2 cm / 20.6 inches
	□□□□□□	37.87 cm / 14.9 inches
Power Input	□□□□	16.18 cm / 6.37 inches
	DC 12V 3A	
AC Adapter	□□□□□□	AC 100-240V, 50 - 60Hz, 1.2A - 0.6A
	□□□□□□□□	DC 12V $\equiv$ 3A $\ominus$ $\oplus$
Weight	□□□	5.1 kg / 11.24 lbs (without speaker)
		6.1 kg / 13.4 lbs
Tilt Range	□□□□	5°
	□□	30°
Environment Conditions	□□□□□□□□□□□□□□	
	□□□□ □□□□□□□□	10°C to 35°C
	□□□□ □□□□	10% to 80% non-condensing
	□□□□□□□□□□□□□□	
	□□□□ □□□□□□□□	-20°C to 60°C
	□□□□ □□□□	5% to 95% non-condensing

NOTE

- Information in this document is subject to change without notice.

ATT