





11ax_HE80_242T (Band 7)










11ax_HE80_242T (Band 8)







11ax_HE80_484T (Band 5)









11ax_HE80_484T (Band 6)




11ax_HE80_484T (Band 7)




Port 1_Middle Channel (6 705 MHz)_65 RU




Port 2_Middle Channel (6 705 MHz)_65 RU




Port 1_Middle Channel (6 705 MHz)_66 RU





Port 2_Middle Channel (6 705 MHz)_66 RU






11ax_HE80_484T (Band 8)







11ax_HE80_996T (Band 5)




11ax_HE80_996T (Band 6)




11ax_HE80_996T (Band 7)




11ax_HE80_996T (Band 8)




11ax_HE80_SU (Band 5)




11ax_HE80_SU (Band 6)



11ax_HE80_SU (Band 7)



11ax_HE80_SU (Band 8)



11ax_HE80L_26T (Band 5)

