


11. SETUP PHOTOS

ANTENNA PORT CONDUCTED RF MEASUREMENT SETUP



RADIATED RF MEASUREMENT SETUP FOR PORTABLE CONFIGURATION

STANDARD OR INDUCTIVE COVER

X-AXIS FRONT PHOTO



Y-AXIS FRONT PHOTO



Z-AXIS FRONT PHOTO



X-AXIS WITH AC ADAPTER FRONT PHOTO (worst-case)



INDUCTIVE CHARGER WITH INDUCTIVE COVER

RADIATED EMISSION FRONT PHOTO



RADIATED EMISSION BACK PHOTO



POWERLINE CONDUCTED EMISSIONS MEASUREMENT SETUP

STANDARD OR INDUCTIVE COVER




LINE CONDUCTED BACK PHOTO



INDUCTIVE CHARGER WITH INDUCTIVE COVER

LINE CONDUCTED FRONT PHOTO



LINE CONDUCTED BACK PHOTO



END OF REPORT