




## 2. Your Phone



# 2. Your Phone

## Keypad Names and Functions



| KEY NAME                              | FUNCTION                                                                                                                      |
|---------------------------------------|-------------------------------------------------------------------------------------------------------------------------------|
| ①  (Power and END/Soft key right) key | Ends a call or turns your phone on and off. In the text line at the bottom of display, performs the functions.                |
| ②  (SEND/Soft key left) key           | Initiates and answers a call. In the text line at the bottom of display, performs the functions.                              |
| ③  (MENU) key                         | Enters menu mode.                                                                                                             |
| ④  (Up) key                           | In standby mode, shows the last numbers dialed. In the menu mode or within a list, moves the cursor up to select an item.     |
| ⑤  (Down) key                         | In standby mode, shows the last numbers received. In the menu mode or within a list, moves the cursor down to select an item. |
| ⑥  (CLR) (CLEAR) key                  | Clears your entry or corrects wrong item.                                                                                     |
| ⑦ Digit keys                          | Enter phone numbers, alphanumeric information, etc.                                                                           |
| ⑧  (*) key                            | Enters *. Holding this key will show "+", which is used in placing international calls.                                       |
| ⑨  (#) key                            | Enters #. Holding this key will display "P", which is used for DTMF sending.                                                  |