


FR540 Operation Manual



Function Button

It is to select function. Function selection is started after press this button and finished after trip for one round or wait a 5 second without key action.

Power button

Turn the radio on by the "POWER" button. The beep sound will be generated after about 3second and the LCD segments include whole icons will come on , indicating the radio has passed a self-check.
If you want to turn-off the radio, press & hold the "POWER" button for about 2 second.

Volume level control

If you want to control the receiving audio level, press "^ (Up)" or "v (Down)" button.
Levels will indicate as bar numbers on the right side of LCD.
Press & Hold "^ (Up)" or "v (Down)", levels will be varied automatically.
Level control operation is always priority whenever press "^" or "v" button..

Channel selection

Press "Function" button repeatedly until a two Large segments blink.
Press "^" or "v" button to select the desired channel.
If you want to fix the selected channel, press "Function" button again . And channel selection will be terminated .

Channel Scanning

AUDIOVOX CORPORATION
FCC ID: BGAFR540
JOB # 128AK0
EXHIBIT # 9A

Press "Function" button repeatedly until "Scan" icon blinks.

Press "^" or "v" button until icon is fixed. Channel scanning will be done after function operation is terminated or wait a 5 second. If there is any carrier signal or "PTT" button is pressed, scanning will be stopped

If re-scanning is required, press "^" button again. Scanning will be continued until there is any carrier signal or "PTT" button is pressed.

If you want to terminate channel scanning, press "Function" button and repeat the above until icon is disappeared.

key tone Selection

Press "Function" button repeatedly until "Tone" icon blinks.

Press "^" or "v" button until icon is fixed. This function will be started to operate after function operation is finished. If then, key tone will be rung whenever any buttons are pressed except Monitor & PTT.

If you don't want key tone, press function button and repeat the above until icon will be disappeared. After function operation is finished, key tone will not be rung.

CTCSS Selection

Press "Function" button repeatedly until CTCSS channel icon blinks.

Press "^" or "v" button to select the desired channel.

If you want to fix the selected channel, press "Function" button again.

If you want to cancel this function, press "Function" button repeatedly until CTCSS channel icon blinks. press "^" or "v" button to select a "00" and press "Function" button again.

VOX Selection

Press "Function" button repeatedly until "VOX" icon blinks.

Press "^" or "v" button until "VOX" icon is fixed. This function will be started to operate after function operation is finished.

If you want to cancel this function, press function button and repeat the above until icon is disappeared. After function operation is finished, vox operation will be terminated.

Key Lock

This function provides the wrong - operation. Under locking, only "function" & PTT operations are permitted.

Press the "Function" button repeatedly until "lock" icon blinks. Press "^" or "v" button until icon is fixed. This function will be started to operate after function operation is finished.

If you want to release Key lock, repeat the above and remove icon.

Power Save

It is always fixed whenever power saving is done.

TX indicator

If PTT button is pressed, "TX" icon will be appeared while transmitting.

Call indicator

If Call button is pressed, "Call" icon will be appeared while transmitting.

RX indicator

If there is any carrier signal during stand-by, "Busy" icon will be appeared.

Low battery alert

If the battery voltage is low, "Battery low" icon will be appeared with beep sound for 1 minute and the radio will eventually turn off with three low pitch beat sound.

AUDIOVOX CORPORATION
FCC ID: BGAFR540
JOB # 128AK0
EXHIBIT # 98

Monitor operation

You can monitor a channel by the button "M ".

By pressing the button "M" over 2 second, the monitoring will be continued.

While you monitors channels , this function will be terminated by pushing the "M" button one more.

AUDIOVOX CORPORATION
FCC ID: BGAFR540
JOB # 128AK0
EXHIBIT # 9c