

4.5 Back View of the WebPAD



- ❶ Battery Connector Cover
- ❷ Battery Pack
- ❸ Battery Latch
- ❹ Battery Release Switch
- ❺ IDE CompactFlash Card Slot Cover

Label Location



- ❶ Backup Battery and RTC Battery Cover
- ❷ Back Stand / Handle