

DENON®

DHT-S517

Dolby Atmos Soundbar & Wireless Subwoofer

Quick Start Guide

Kurzanleitung / Guide de démarrage rapide / Guida di Avvio Rapido /
Guía de inicio rápido / Snelhandleiding / Snabbstartsguide /
Краткое руководство пользователя / Skrócona instrukcja obsługi

Read Me First....

Bitte zuerst lesen... / Lisez-moi en premier.... / Nota preliminare.... /
Lea esto primero.... / Lees mij eerst... / Läs detta först... /
Прочитайте в первую очередь... / Przeczytaj to najpierw....

ENGLISH

DEUTSCH

FRANÇAIS

ITALIANO

ESPAÑOL

NEDERLANDS

SVENSKA

РУССКИЙ

POLSKI

Welcome

Thank you for choosing a Denon TV Sound system.
This guide provides step-by-step instructions for setting up your TV Sound system.

Before You Begin

What You Need



TV




- These drawings are for illustrative purposes only and may not represent the actual product(s).

What's In the Box



Sound bar




Subwoofer




Quick Start Guide



Safety Instructions




Cautions on Using Batteries




Wall mount template



Power cords




HDMI cable (4K)



Optical digital cable




Wall mount spacers



Remote control unit
(RC-1245 / Built-in battery)

Before using the remote control unit




Setup

There are six steps to the setup process.


- 1** Placing the Sound bar
- 2** Placing the Subwoofer
- 3** Connecting the Sound bar to TV
- 4** Connecting the power cords to AC outlet
- 5** Using the Sound bar for TV sound
- 6** Using the Sound bar for Bluetooth music streaming

1 Placing the Sound bar

Place the Sound bar in front of the TV.




- The Sound bar can also be mounted to a wall. Refer to the included wall mount template for details on how to mount.
- If you want to install your Sound bar on a wall, please refer to the Owner's Manual for mounting instructions or contact your Denon dealer for assistance.




2 Placing the Subwoofer

Place the Subwoofer on the floor near the Sound bar.




3 Connecting the Sound bar to TV

For TVs with eARC (Enhanced Audio Return Channel)/ARC (Audio Return Channel) support, connect the Sound bar to the TV with the included HDMI cable.




- If the TV does not support eARC/ARC, connect it to the Sound bar using the included HDMI cable and optical digital cable.



4 Connecting the power cords to AC outlet


Connect the included power cords to the Sound bar and Subwoofer, and insert the plugs into an outlet.

- Turn on the Sound bar and the LED on the back of the Subwoofer will change from off to green.



5 Using the Sound bar for TV sound


Turn on your TV.



- If you hear audio coming from TV's internal speaker, make sure TV speaker off or min volume.

About the status LEDs



The LEDs on the Sound bar indicate the power, input source, or audio format and other status information.



6 Using the Sound bar for Bluetooth music streaming

Before you can stream music from your Bluetooth device to the Sound bar, you must first “pair” the Sound bar and your device.

- ① Press the  (Bluetooth) button on the Sound bar (or remote control unit) until the Bluetooth LED blinks in blue. Sound bar will go into the pairing mode.
- ② Go to the Bluetooth settings on your device and make sure Bluetooth is turned ON.



- ③ Select “DHT-S517 (Default)”.
The status LED turns blue to indicate that the Sound bar is being paired with your Bluetooth device.




Owner's Manual

- For more information, visit **www.denon.com**
- Refer to the Online Manual for other functions information and operation procedure details.
manuals.denon.com/DHTS517/EU/EN/



Online Manual





DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP









DUMMY FOR LPP









DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP

DUMMY FOR LPP





DENON®
www.denon.com

Printed in China **** * 00AD
© 2021 Sound United. All Rights Reserved.