


Loop Antennas Data Sheet

Type:	Loop Antenna
Polarization:	Linear
Pattern Type:	Omidirectional
Frequency Minumum:	100 Hz
Frequency Maximum:	60 KHz



Model/Module	Product Code	P/N	Channel (X/Y)	Gain (dBi)	Type
AMB 5014	ZBAMB6001	1811-0103-02	X	-122	Loop, Air Core
AMB 5195	ZBAMB6003	1811-0103-04	X	-121	Loop, Air Core
AMB 5500	ZBAMB6002	1811-0103-03	X	-129	Loop, Air Core
AMB-5010	ZBAMB5010A2	0404-0739-01	X	-116	Loop, Air Core
AMB-5010	ZBAMB5010A	0505-4514-01	Y	-117	Loop, Air Core
AMB-5010	ZBAMB5010A	0404-0571-01	X	-117	Loop, Air Core
AMB-5014	ZBAMB5014A	0101-0857-01	Y	-125	Loop, Air Core
AMB-5120	ZBAMB5120H	0101-0525-01	X	-121	Loop, Air Core
AMB-5184	ZBAMB5184A	0404-0542-01	X	-117	Loop, Air Core
AMB-5190	ZBAMB5190A	0101-0340-01	X	-116	Loop, Air Core
AMB-5194	ZBAMB5194L	0101-0716-01	X	-121	Loop, Air Core
AMB-5196	ZBAMB5196A	0101-0853-01	X	-121	Loop, Air Core
AMB-5199	ZBAMB5199A	0101-0847-01	X	-122	Loop, Air Core
AMB-5212	ZBAMB5212A	0101-0786-01	X	-119	Loop, Air Core
AMB-5274	ZBAMB5274H	0404-0603-01	X	-119	Loop, Air Core
AMB-5274	ZBAMB5274V	0404-0604-01	Y	-121	Loop, Air Core
AMB-5277	ZBAMB5277H	0101-0728-01	X	-119	Loop, Air Core
AMB-5277	ZBAMB5277V	0101-0729-01	Y	-120	Loop, Air Core
AMB-5278	ZBAMB5278A	0101-0240-01	X	-124	Loop, Air Core
AMB-5279	ZBAMB5279A	0101-0786-01	X	-119	Loop, Air Core
AMB-5290	ZBAMB5290A	0404-1133-01	X	-132	Loop, Air Core
AMB-5310	ZBAMB5318V	0101-0543-01	X	-115	Loop, Air Core
AMB-5310	ZBAMB5318H	0101-0542-01	Y	-115	Loop, Air Core
AMB-5410H	ZBAMB5410H	0101-0569-01	X	-127	Loop, Air Core
AMB-5410V	ZBAMB5410V	0101-0570-01	Y	-118	Loop, Air Core
AMB-5470	ZBAMB5470A	0101-0726-01	X	-115	Loop, Air Core
AMB-5472	ZMANB5472A	0404-1422-01	X	-119	Loop, Air Core
AMB-5780	ZBAMB5780	0201-0019-01	X	-114	Loop, Air Core
AMB-5900	ZBAMB5900A	0404-1410-01	X	-118	Loop, Air Core
ANAMB-2302	1811-0103-01	1811-0103-01	X	-113	Loop, Air Core
ANAMB-2402	1811-0104-01	1811-0104-01	X	-110	Loop, Air Core
DEAC STP-CD	ZBSMPCPE	0304-0038-03	X	-122	Loop, Ferrite Core
DEAC STP-CD	ZBSMPCPE	0304-0038-03	Y	-123	Loop, Ferrite Core
DEAC STP-LD	ZBSMPLPE	0304-0036-03	X	-119	Loop, Ferrite Core
DEAC STP-LD	ZBSMPLPE	0304-0036-03	Y	-119	Loop, Ferrite Core
DEAC STP-LP	ZBSMPLP	0304-0036-01	X	-118	Loop, Ferrite Core
DEAC STP-PD	ZBSMPPPE	0304-0034-02	X	-119	Loop, Ferrite Core
DEAC STP-PD	ZBSMPPPE	0304-0034-02	Y	-120	Loop, Ferrite Core
DEAC STP-SD	ZBSMPSP	0304-0035-01	X	-118	Loop, Ferrite Core