


Model 1846 – Label Location



Label located on bottom side of the module