


Model 1888 – Label Location



Label located on radio module shield top of EUT