



Thunderbolt™ 4 / USB 4.0



Studio Mics  
Micros de studio  
Micrófonos de estudio



Headphone jack  
Prise de casque  
Conexión de auriculares



Windows Hello camera  
Caméra Windows Hello  
Cámara de Windows Hello



Power button  
Bouton d'alimentation  
Botón de encendido





Surface Slim Pen storage (pen sold separately)  
Rangement du stylet mince Surface (stylet vendu séparément)  
Almacenamiento del Surface Slim Pen (el lápiz se vende por separado)




Front-facing camera  
Caméra à l'avant  
Cámara frontal



Surface Connect port  
Port Surface Connect  
Puerto Surface Connect



[aka.ms/LaptopStudioModes](https://aka.ms/LaptopStudioModes)



Charge and store a Surface Slim Pen  
Permet de charger et de ranger un stylet mince Surface  
Cargar y almacenar un Surface Slim Pen

[support.microsoft.com](https://support.microsoft.com)



©2021 Microsoft.



M1188447-001