



Truck Use




- Slide the **on/off** switch to turn the truck power on or off.

Hint: The truck power will turn **off** automatically after a few minutes of non-use. **To** turn the truck power **back** on, slide the on/off switch to the on position.


Monster Truck - Low Speed



Racing Truck - High Speed



Transmitter Use



- **FORWARD** - Push the top arrow on the transmitter control button.
- **REVERSE** - Push the bottom arrow on the transmitter control button.
- **STOP** - Release the transmitter control button.
- **LEFT** - Turn the transmitter wheel to the left.
- **STRAIGHT** - Keep the transmitter wheel straight.
- **RIGHT** - Turn the transmitter wheel to the right.

Good Driver Tips

- For maximum range, keep the transmitter antenna pointed up.
- Operate the truck in a dry, open area, away from any street or moving (motorized) vehicles.
- Avoid using this toy near sand and water.
It moisture does get inside the truck or transmitter, remove the batteries and allow the units to dry for several hours before next use.
- Store your truck and transmitter inside after play, away from heat or direct sunlight.
- Do not carry the truck or transmitter by the antenna.