

2.7 Conducted emission test setup Configuration X (front).



2.8 Conducted emission test setup Configuration X (back).





2.9 Conducted emission test setup Configuration XI (front).



2.10 Conducted emission test setup Configuration XI (back).





2.11 Conducted emission test setup Configuration XII (front).



2.12 Conducted emission test setup Configuration XII (back).





2.13 Conducted emission test setup Configuration XIII (front).

