

Ad-hoc mode for MB44

- Ad-hoc channel on 2.4GHz
 - Ad-hoc default: ch10 for all SKU.
 - Ad-hoc is supported in 11b mode only.
 - 11g does not support Ad-hoc.
 - Ad-hoc will work on Ch1-11 for MoW SKU
 - Ad-hoc on ch12,13,14 is disabled.
 - Ad-hoc will work on Ch1-13 for RoW SKU
 - Ad-hoc on ch14 is disabled.
 - Ad-hoc will work on Ch1-14 for JP SKU
 - Ad-hoc on ch14 is disabled.
- Ad-hoc channel on 5GHz
 - All channels of all SKUs are disabled.