LOCATION	FLX-A-DAM-X5
Inside of a COVER 	
Outside of a BASE