TITLE

ART, BOX, STANDALONE
SAGE HUB (US)

DWG. NO	REV
207137	01

DRAWN	DATE
Jason Walker	02/19/15

SCALE: 1:1 SHEET 1 of 1

NOTES

SEE PRINT SPEC FOR ADDITIONAL PRINTING REQUIREMENTS.

SAGE
by HUGHES
SECURITY & HOME AUTOMATION

Works with most tablets and mobile devices and is available on:

Download on the App Store | GET IT ON Google play

Visit SAGEbyHughes.com for updated browser support, hardware, operating system and network bandwidth requirements.

Video quality is dependent on network devices and conditions.

SAGE and Hughes are trademarks of EchoStar Technologies L.L.C. or its affiliates.

Federal Communications Commission and IC Notices

This Class B digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe B est conforme a la norme NMB-003 du Canada.

This device complies with Part 15 of the FCC Rules and with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

1. l'appareil ne doit pas produire de brouillage, et
2. l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by following one or more of the following measures:

1. Reorient or relocate the receiving antenna.
2. Increase the separation between the equipment and receiver.
3. Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
4. Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications to this device may void your authority to operate this equipment.

Device must be installed at least 20cm (~8 inches) from typical person locations per FCC RF Exposure guidelines.

Operation in the band 5150-5250 MHz is only for indoor use to reduce the potential for harmful interference to co-channel mobile satellite systems.

Les dispositifs fonctionnant dans la bande 5150-5250 MHz sont réservés uniquement pour une utilisation à l'intérieur afin de réduire les risques de brouillage préjudiciable aux systèmes de satellites mobiles utilisant les mêmes canaux.

IC Interim Notice

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

Avis d'Industrie Canada sur les antennes

Conformément à la réglementation d'Industrie Canada, le présent émetteur radio peut fonctionner avec une antenne d'un type et d'un gain maximal (ou inférieur) approuvé pour l'émetteur par Industrie Canada. Dans le but de réduire les risques de brouillage radioélectrique à l'intention des autres utilisateurs, il faut choisir le type d'antenne et son gain de sorte que la puissance isotrope rayonnée équivalente (p.i.r.e.) ne dépasse pas l'intensité nécessaire à l'établissement d'une communication satisfaisante.

Limited Warranty

A 12 month Limited Warranty covers this SAGE kit. Limited Warranty details are available at:

SAGEbyHughes.com/warranty

To view customer agreement, go to SAGEbyHughes.com/customer-agreement

E LTE. E421334 ID:087 — HDMI HIGH-DEFINITION MULTIMEDIA INTERFACE — MADE IN MEXICO P/N: 206404

SAGE and Hughes are trademarks of EchoStar Technologies L.L.C. or its affiliates.

Seamlessly transition between TV and SAGE using picture-in-picture controls

Securely monitor and manage your SAGE Home Automation system from your connected devices.

Experience peace of mind with multiple alerts sent simultaneously to all enabled devices

Securely communicate with your connected devices

Integrate with a variety of SAGE-approved devices, including door and window sensors, cameras, motion sensors, wall switches, lights, locks, and thermostats

Create custom rules such as morning wake-up, daytime thermostat levels, and nighttime security checks

Important Safety Instructions

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Clean only with a dry cloth.
5. Do not use this product near water or where spilled liquids are likely.
6. Do not block any ventilation openings.
7. The power supply must be readily accessible so that the product can be easily disconnected from the AC power.
8. This product contains a compartment for rechargeable batteries. Before inserting or replacing batteries, be sure to read all instructions.
9. Use only the power supply specified for this product.
10. Never insert AA Alkaline or lithium batteries into the product.
11. Use only AA Nickel Type rechargeable batteries in this product.
12. Dispose of used batteries at a retail recycling drop off in accordance with local codes.
13. Do not expose batteries to excessive heat or fire.
14. Do not place any objects on top of the product.
15. Do not operate in a maximum ambient operating temperature of 113°F.
16. Do not place the product inside an enclosure without proper ventilation.

CAUTION - Risk of explosion if battery is replaced by an incorrect type. Dispose of used batteries according to the instructions.

Consignes de Sécurité Importantes

1. Lisez ces consignes.
2. Conservez ces consignes.
3. Respectez tous les avertissements.
4. Suivez toutes les instructions.
5. Ne nettoyez pas l'appareil avec un chiffon sec uniquement.
6. Ne bouchez pas les orifices d'aération.
7. Ne placez pas d'objets sur le produit.
8. Ce produit possède un emplacement pour batteries rechargeables. Avant d'insérer ou de remplacer les batteries, débranchez le produit de la prise électrique.
9. Pour ce produit, utilisez uniquement des batteries rechargeables de type AA Nikel.
10. N'insérez jamais de batteries AA alcaline ou lithium dans ce produit.
11. N'exposez jamais les batteries à une chaleur excessive ou au feu.
12. Mettez les batteries usagées à un point de recyclage après, conformément aux normes locales.
13. Utilisez uniquement la prise électrique fournie avec le produit. Débranchez la prise électrique en cas d'orage ou lorsque vous ne l'utilisez pas pendant de longues périodes.
14. Ne placez pas le produit dans un endroit clos sans une ventilation adaptée.

ATTENTION—Il y a danger d'explosion s'il y a remplacement incorrect de la batterie. Mettre au rebut les batteries usagées conformément aux instructions du fabricant.

15. Ne dépassez pas la température ambiante maximale de fonctionnement de 45 °C.

Securely communicate with your connected devices

Integrate with a variety of SAGE-approved devices, including door and window sensors, cameras, motion sensors, wall switches, lights, locks, and thermostats

Create custom rules such as morning wake-up, daytime thermostat levels, and nighttime security checks

Getting Started

1 Disconnect your existing AV source (e.g., satellite, Cable) from the TV, and connect it to the HDMI In port on the SAGE Hub's back panel.

2 Using the included HDMI cable, connect the HDMI cable from the HDMI Out port on the SAGE Hub's back panel to your TV.

3 Plug the power adapter into a wall outlet not controlled by a wall switch.

SAGE Hub powers on.

SAGE
by HUGHES
SECURITY & HOME AUTOMATION

HOME AUTOMATION HUB

SAGE makes security and home automation simple, conveniently putting control of your home on your TV and mobile devices!

SAGE Approved

Integrate with a variety of SAGE-approved devices, including door and window sensors, cameras, motion sensors, wall switches, lights, locks, and thermostats

SAGEbyHughes.com

Images are not to scale; actual product may vary slightly from what is shown on box.

HOME AUTOMATION HUB

Box Contents:

1—Home Automation Hub
1—Power Supply
1—Remote Control with 2 AA Batteries
1—HDMI Cable

SAGEbyHughes.com

SAGE
by HUGHES
SECURITY & HOME AUTOMATION

For additional information go to SAGEbyHughes.com

4 Insert the batteries into the SAGE remote, using the diagram inside the case to ensure the batteries are positioned correctly.



5 Follow the on-screen instructions to pair the remote, complete set-up, and install the devices included in your kit.

ECHOSTAR