




## SpeechLine Digital Wireless SL MCR DW

### Quick Guide

Kurzanleitung  
Guide de démarrage rapide  
Guida rapida  
Instrucciones resumidas  
Beknopte gebruiksaanwijzing  
Krótka instrukcja obsługi  
Snabbguide

Kort vejledning  
Pikaohje  
Γρήγορος οδηγός  
Kısa Kılavuz  
Краткая инструкция  
快速指南  
快速使用指南  
クイックガイド  
퀵 가이드

SENNHEISER



### Sennheiser Documentation App




or online at  
[www.sennheiser.com/download](http://www.sennheiser.com/download)  
SpeechLine Digital Wireless\_

Sennheiser electronic GmbH & Co. KG


Am Labor 1, 30900 Wedemark, Germany  
[www.sennheiser.com](http://www.sennheiser.com)

Printed in Germany, Publ. 01/20, 583940/A01


### In the box




### Connecting




### Single Cable Mode (Factory Default)



### Audio Redundancy Mode




### Split Mode




Configuration via Audinate Dante Controller | [www.audinate.com](http://www.audinate.com)

### Cable Routing



### Wall



\*not included

