




Antennas



*optional accessories:
ADP UHF (470 - 1075 MHz)
AD 1800 (1400 - 2400 MHz)



Instruction Manual

EW-D Smart Assist

Download on the App Store

GET IT ON Google Play

Sennheiser Documentation App

Download on the App Store

GET IT ON Google Play

or online at www.sennheiser.com/download

EW-DX

Sennheiser electronic GmbH & Co. KG

Am Labor 1, 30900 Wedemark, Germany

www.sennheiser.com

Printed in Germany

Publ. 04/22, 587467/A01



Evolution Wireless Digital

EW-DX EM 2
EW-DX SK
EW-DX SKM

Quick Guide

Kurzanleitung

Guide rapide

Guida rapida

Guía de inicio rápido

Guia rápido

Beknopte handleiding

Krótką instrukcją obsługi

Snabbguide

Kort vejledning

Παράοδη

Γρήγορος οδηγός

Kısa Kılavuz



Краткая инструкция

快速指南

クイックガイド

퀵 가이드

Audio Out



6.3 mm

XLR-3

EU

US

UK


AU

KOR

CN

Power supply

Remote control



EW-D Smart Assist App

Wireless Systems Manager (WSM)

www.sennheiser.com/wsm


Sennheiser Control Cockpit (SCC)

www.sennheiser.com/control-cockpit-software

Download on the App Store

GET IT ON Google Play

In the box




Rack mount angles

Power supply adapters

Power supply

Battery



SK

SKM(-S)



2 AA batteries

BA 70 rechargeable battery

2 AA batteries

BA 70 rechargeable battery

EW-DX EM 2



Headphone output

LED ch. 1

Channel 1

UP

SET

ESC

Headphone volume control

LED ch. 2

Channel 2

Display

DOWN

SYNC

ON/OFF


PoE / Network control (WSM / SCC)

Audio outputs

Antenna inputs

Power supply

On/Off



EM

Off -> On

EM/SK/SKM(-S)

short on

SKM(-S)

On -> Off


EM/SK/SKM(-S)

long off

SK

Identify/Battery check

EW-DX SKM-S | EW-DX SKM



ON/OFF

DATA LED

ESC

UP

Display

LINK LED


SYNC

DOWN

SET

MUTE (EW-DX SKM-S)

EW-DX SK | EW-DX SK 3-PIN



EW-DX SK

3.5 mm jack

EW-DX SK 3-PIN

3 pin socket

LINK LED

DATA LED

SYNC

MUTE

Display

ON/OFF

ESC

DOWN




SET

UP

Display & Menu







System Home Screen





LEDs

LED Ch.1/2 (EM 2) LINK LED (SK/SKM)	
	- Link ok - audio active
	- Link ok - audio muted or no capsule on SKM
	- Link ok - audio clip
	- No link
	- Link ok - Low transmitter battery
	- No link - Device switched off

LED Ch.1/2 (EM 2) DATA LED (SK/SKM)	
	Bluetooth active to - sync with transmitter - connect with app
	Firmware update in progress




Sync





Auto Setup

Mute



Key Lock



Instruction manual | Bedienungsanleitung | Notice d'emploi | Istruzioni per l'uso |
Instrucciones de manejo | Manual de instruções | Gebruiksaanwijzing |
Instrukcja obsługi | Bruksanvisning | Betjenings vejledning | Käyttöohje |
Οδηγίες λειτουργίας | Kullanım kılavuzu | Инструкция по эксплуатации | 使用说明书 |
取扱説明書 | 사용 설명서 |

Sennheiser Documentation App

Available on the **App Store**

EW-D Smart Assist

Available on the **App Store**