




Antennas




*optional accessories:
ADP UHF (470 - 1075 MHz)
AD 1800 (1400 - 2400 MHz)


Audio Out




Power supply




Battery




SKM-S



On/Off



Identify/Battery check



EW-D Smart Assist

The EW-D Smart Assist app simplifies your workflow

- EW-D Smart Assist app provides automated setup, operation and monitoring using any iOS or Android device
- Intelligent setup automatically creates reliable wireless connections, no wireless expertise required
- Mobile access to all system settings centralizes control and eliminates the need for complicated menu navigation on each device
- Easy frequency allocation and wireless channel naming help to keep systems organized



Evolution Wireless Digital

- Quick Guide
- Kurzanleitung
- Guide rapide
- Guida rapida
- Guia de inicio rápido
- Guia rápido
- Beknopte handleiding
- Krótka instrukcja obsługi
- Snabbguide
- Kort vejledning
- Pikaohje
- Γρήγορος οδηγός
- Kısa Kılavuz
- Краткая инструкция
- 快速指南
- クイックガイド
- 퀵 가이드


Sennheiser electronic GmbH & Co. KG

Am Labor 1, 30900 Wedemark, Germany
www.sennheiser.com



Printed in Germany
Publ. 04/20, 583962/A01

SENNHEISER


In the box




EW-D EM




EW-D SKM-S



EW-D SK



Display



Menu

Gain

AF Out

Mute Lock

Auto Scan

Channel

Tune

Reset

Instruction manual | Bedienungsanleitung | Notice d'emploi | Istruzioni per l'uso | Instrucciones de manejo | Manual de instruções | Gebruiksaanwijzing | Instrukcja obsługi | Bruksanvisning | Betjenings vejledning | Käyttöohje | Οδηγίες λειτουργίας | Kullanım kılavuzu | Инструкция по эксплуатации | 使用说明书 | 取扱説明書 | 사용 설명서 |

EW-D Smart Assist

Available on the App Store

ANDROID APP ON Google play

Sennheiser Documentation App


Available on the App Store

ANDROID APP ON Google play


LEDs

LINK LED	
	- Link ok - audio active
	- Link ok - audio muted or no capsule on SKM
	- Link ok - audio clip
	- No link
	- Link ok - Low transmitter battery
	- No link - Device switched off


EM



SKM-S




SK



DATA LED

	Bluetooth active to - sync with transmitter - connect with app
	Firmware update in progress



Mute

Mute Lock → Instruction Manual

SK

SKM-S

SKM-S

Sync

EM

SKM-S

SK

short press

1

2 OR

short press

short press

Instruction Manual

Key lock

press both

unlocked

locked

Instruction Manual

Color coding sets

optional accessories for EM, SK and SKM-S

wireless link 1:

wireless link 2:

etc.

etc.

Instruction Manual

ME 2

ME 3

ME 4

25 cm (10")

2...3 cm (1")