

Quick Start

Quick Start

Regulatory Model/Type

Venue 10

T13G / T13G001





Read the safety information that shipped with your computer. For additional safety best practices information, see the Regulatory Compliance Homepage at www.dell.com/regulatory_compliance.



Do not remove the computer cover unless you need to install internal accessories for your computer. For instructions on removing and replacing parts, see the *Owner's Manual* at dell.com/support.



Retain the filler brackets or cards that ship with your computer. Installing filler brackets or filler cards over empty card-slot openings is necessary to maintain FCC certification of the computer. The filler brackets and filler cards keep dust and dirt out of your computer and maintain the airflow that cools your computer.

Power Adapter

Input voltage



Input current (maximum)

Input frequency


Output current

Output voltage


Connect the power adapter or the power cable to your computer and to the display, if required.



Connect the network cable (optional).



Power on the computer (and the display, if connected).






Depending on your computer configuration, some ports or connectors may not be available.

Icons

Power adapter



USB



USB with PowerShare



eSATA

eSATA

Thunderbolt



Network



VGA



DVI



HDMI

HDMI

DisplayPort



Mini DisplayPort



TV-in



Infrared (IR) emitter



Headphone/Audio-out



Icons

Headset/Audio-out



Microphone



Line-in



Line-out/Speakers: front left-right



Speakers: rear left-right



Speakers: side left-right




Speakers: Audio center/subwoofer



S/P DIF

S/P DIF

Screen-rotation lock



SIM-card slot



ExpressCard slot

EC

Media-card reader



MMC.SD.MS/PRO

Security-cable slot



Power/Battery-status light



Icons

Battery-status light



Hard-drive activity light



Wi-Fi light



Bluetooth light

