

TABLE OF CONTENTS

<u>Par. No.</u>	<u>Section 1 General Description</u>	<u>Page No.</u>
1-1	Introduction.....	1-1
1-2	General Description.....	1-1
1-3	Functional and Physical Specifications.....	1-1
	 <u>Section 2 Installation</u>	
2-1	Introduction.....	2-1
2-2	Electrical Service Recommendations.....	2-1
2-3	Unpacking and Inspection	2-1
2-4	Installation Instructions	2-2
2-5	+26 VDC Power and Ground Connector P1.....	2-2
2-6	Alarms and Sensing Connector P2.....	2-3
2-7	Differential IIC Clock, Receive, and Transmit Connector P3.....	2-4
2-8	IIC, Power, Alarms, and Controls Connector P4.....	2-4
2-9	IIC, RS485, Power, and Other Signals Connector P5.....	2-6
	 <u>Section 3 Operating Instructions</u>	
3-1	Introduction.....	3-1
3-2	Initial Start-Up and Operating Procedures	3-1
	 <u>Section 4 Principles of Operation</u>	
4-1	Introduction.....	4-1
4-2	RF Input Signal	4-1
4-3	RF Output Load.....	4-1
4-4	Amplifier Functional Description.....	4-1
4-4.1	Input Amplifier	4-1
4-4.2	Predistortion Amplifier.....	4-1
4-4.3	Driver Amplifier	4-2
4-4.4	Main Amplifier	4-2
4-4.5	Multifunction Board.....	4-2
4-5	Amplifier Module Cooling.....	4-2
4-5	Power Distribution	4-2

TABLE OF CONTENTS (Continued)

<u>Par. No.</u>	Section 5 Maintenance	<u>Page No.</u>
5-1	Introduction.....	5-1
5-2	Periodic Maintenance	5-1
5-3	Test Equipment Required For Test.....	5-1
5-4	Performance Test	5-2
5-4.1	Amplifier Performance Test.....	5-2
5-5	Field Replacement of the Module	5-5

Section 6 Troubleshooting

6-1	Introduction.....	6-1
6-2	Troubleshooting.....	6-1
6-3	Return for Service Procedures.....	6-1
6-3.1	Obtaining an RMA	6-1
6-3.2	Repackaging for Shipment.....	6-1

LIST OF ILLUSTRATIONS

<u>Figure No.</u>		<u>Page No.</u>
1-1	NTGY81AA Multichannel Power Amplifier	1-3
2-1	+26 Vdc Power and Ground Connector P1.....	2-2
2-2	Alarms and Sensing Connector P2.....	2-3
2-3	Differential IIC Clock, Receive, and Transmit Connector P3.....	2-4
2-4	IIC, Power, Alarms, and Controls Connector P4.....	2-4
2-5	IIC, RS485, Power and Other Connector P5.....	2-6
4-1	NTGY81AA Multichannel Power Amplifier Functional Block Diagram	4-2
5-1	NTGY81AA Amplifier Test Setup Diagram.....	5-3

LIST OF TABLES

<u>Table No.</u>		<u>Page No.</u>
1-1	NTGY81AA Multichannel Power Amplifier Functional Specifications.....	1-2
2-1	+26 Vdc Power and Ground Connector P1 Definition.....	2-2
2-2	Alarms and Sensing Connector P2 Definition	2-3
2-3	Differential IIC Clock, Receive, and Transmit Connector P3 Definition.....	2-4
2-4	IIC, Power, Alarms, and Controls Connector P4 Definition	2-5
2-5	IIC, RS485, Power and Other Connector P5 Definition.....	2-6
5-1	Periodic Maintenance	5-1
5-2	Test Equipment Required	5-2
5-3	Multichannel Power Amplifier NTGY81AA Test Data Sheet.....	5-4

6-1	Troubleshooting.....	6-1
-----	----------------------	-----