





Dell Premier Rechargeable Wireless Mouse MS7421W


Quick Start Guide




1



3




4




2

1




2




2


1




2







3




3



3✂






<https://www.dell.com/support/drivers>



Dell Peripheral Manager

<https://www.dell.com/support>
https://www.dell.com/regulatory_compliance



2

